

Neles EasyflowTM J4 series 3-piece ball valve DN15 - DN50 (1/2" - 2")





Table of contents

GENERAL Scope of the Manual Valve markings Safety Precautions ATEX marking	3 3 3 3 3
TRANSPORTATION AND STORAGE	4
INSTALLATION General Installing in the Pipeline Valve Insulation Actuator Commissioning	4 4 4 5 5
MAINTENANCE General Actuated Valve Valve Disassembly Checking Parts Valve Assembly Testing the Valve	5 5 5 6 6 6
ACTUATOR Actuator Mounting Instructions	7 7
SERVICE / SPARE PART	7

WELDING WARNING	8
EXPLODED VIEW DN15 TO DN5	9
EU DECLARATION OF CONFORMITY FOR ATEX APPROVED VALVES	10
TYPE CODE	11
NELES EASYFLOW J4 3-PIECE SEAT SUPPORTED BALL VALVE	11
GENERAL SAFETY WARNINGS AND DISCLAIMERS General safety warnings General disclaimers	12 12 12

READ THESE INSTRUCTIONS FIRST!

These instructions provide information about safe handling and operation of the valve.

If you require additional assistance, please contact the manufacturer or manufacturer's representative.

SAVE THESE INSTRUCTIONS!

Addresses and phone numbers are printed on the back cover.

1. GENERAL

1.1 SCOPE OF THE MANUAL

This instruction manual contains important information regarding the installation, operation and maintenance of Neles Easyflow[™] J4 Series full or reduced bore 3-piece seat supported ball valves. Please read these instructions carefully and save them for future reference.

WARNING:

THE USE OF THE VALVE IS APPLICATION SPECIFIC. BE SURE THAT THE VALVE IS SUITABLE FOR ITS INTENDED SERVICE. IF YOU HAVE ANY QUESTIONS CONCERNING THE USE, APPLICATION OR COMPATIBILITY OF THE VALVE WITH THE INTENDED SERVICE, CONTACT VALMET FOR MORE INFORMATION.

1.2 VALVE MARKINGS

The valve has a name plate attached to the valve body or tied to the valve (for valves without flanges). The name plate markings identify the size, materials of construction, pressure rating, month and year of construction, and a unique manufacturing order number.

1.3 SAFETY PRECAUTIONS

WARNING:

DO NOT EXCEED THE VALVE PERFORMANCE LIMITATIONS!

EXCEEDING THE PRESSURE OR TEMPERATURE LIMITATIONS MARKED ON THE VALVE LABEL PLATE MAY CAUSE DAMAGE AND LEAD TO UNCONTROLLED PRESSURE RELEASE. DAMAGE OR PERSONAL INJURY MAY RESULT.

WARNING:

SEAT AND BODY RATINGS!

THE PRACTICAL AND SAFE USE OF THIS PRODUCT IS DETERMINED BY BOTH THE SEAT AND BODY RATINGS. READ THE NAME PLATE AND CHECK BOTH RATINGS. SOME SEAT MATERIALS HAVE PRESSURE RATINGS THAT ARE LESS THAN THE BODY RATING. ALL OF THE BODY AND SEAT RATINGS ARE DEPENDENT ON VALVE TYPE AND SEAT MATERIAL. DO NOT EXCEED THESE RATINGS!

WARNING:

BEWARE OF BALL MOVEMENT!

KEEP HANDS, OTHER PARTS OF THE BODY, TOOLS AND OTHER OBJECTS OUT OF THE OPEN FLOW PORT. LEAVE NO FOREIGN OBJECTS INSIDE THE PIPELINE. WHEN THE VALVE IS ACTUATED, THE BALL FUNCTIONS AS A CUTTING DEVICE. DISCONNECT ANY PNEUMATIC SUPPLY LINES, ANY ELECTRICAL POWER SOURCES AND MAKE SURE SPRINGS IN SPRING-RETURN ACTUATORS ARE IN THE FULL EXTENDED/RELAXED STATE BEFORE PERFORMING ANY VALVE MAINTENANCE. FAILURE TO DO THIS MAY RESULT IN DAMAGE OR PERSONAL INJURY!

WARNING:

WHEN HANDLING THE VALVE OR VALVE/ACTUATOR ASSEMBLY, TAKE ITS WEIGHT INTO ACCOUNT!

NEVER LIFT THE VALVE OR VALVE/ACTUATOR ASSEMBLY BY THE ACTUATOR, POSITIONER, LIMIT SWITCH OR THEIR PIPING /BRACKETS. PLACE LIFTING DEVICES SECURELY AROUND THE VALVE BODY. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY RESULT IN DAMAGE OR PERSONAL INJURY FROM FALLING PARTS (SEE FIGURE 1).

ATEX/EX SAFETY

CAUTION:

Potential electrostatic hazard, ensure the protection (grounding, etc.) in the process.

CAUTION:

The actual surface temperature of valve is depended on the process temperature. The protection from high or low temperature must be considered by the end user before valve is put into service.

CAUTION:

Ensure the general process and worker protection from static electricity in the facilities

1.4 ATEX MARKING

The valve meets the requirements of the European Directive 2014/34/EU relating to equipment and protective systems intended for use in potentially explosive atmosphere, and has been marked according to the Directive.



Figure 1. Lifting of the valve assembly

2. TRANSPORTATION AND STORAGE

Check the valve and the accompanying devices for any damage that may have occurred during transport.

Store the valve carefully. Store indoors in a cool, dry place.

Do not remove the flow port protectors until installing the valve. Move the valve to its intended location just before installation. If the valve(s) are to be stored for a long duration, follow the recommendations of IMO-S1.

3. INSTALLATION

3.1 GENERAL

Remove the flow port protectors and check that the valve is clean inside. Clean valve if necessary.

Flush the pipeline carefully before installing the valve. Foreign objects, such as sand or pieces of welding electrodes, will damage the ball and seats.

3.2 INSTALLING IN THE PIPELINE

WARNING:

DO NOT ATTEMPT TO CORRECT PIPELINE MISALIGNMENT WITH THE VALVE!

The valve may be installed in any position and offers tight shut-off in either flow direction. When in a horizontal line, it is not recommended to install a valve with the stem on the underneath side as debris in the pipeline may enter the body cavity and damage the gland packing.

Refer to Section 4, **MAINTENANCE** for stem seal adjustment. If there is seepage past the stem seal upon installation, it means the valve may have been subject to wide temperature variations in shipment. Leak-tight performance will be restored by a simple stem seal adjustment described in the **MAINTENANCE** section.

SCREWED END INSTALLATION

WARNING:

DO NOT USE HANDLE TO TIGHTEN VALVE ONTO THE PIPE. THE VALVE SHALL BE TIGHTENED ONTO THE PIPE WITH A WRENCH ON THE END CAP NEAREST THE PIPE. PIPE THREADS REQUIRE USE OF THREAD COMPOUND TO SEAL. USE THREAD COMPOUND THAT IS COMPATIBLE WITH THE APPLICATION, AND IN COMPLIANCE WITH APPLICABLE PIPING CODES AND STANDARDS. PLEASE CHECK THE TYPE OF VALVE THREAD END BEFORE APPLYING TORQUE (METRIC OR BSPT OR NPT).

Use standard piping practices to install valves with threaded end connections.

WELD END INSTALLATION

WARNING:

WELDING AND/OR GRINDING STAINLESS STEEL AND OTHER ALLOYS CONTAINING CHROMIUM METAL MAY CAUSE THE RELEASE OF HEXAVALENT CHROMIUM. HEXAVALENT CHROMIUM(VI) OR CR(VI), IS KNOWN TO CAUSE CANCER. BE SURE TO USE ALL APPROPRAITE PPE WHEN WELDING METALS CONTAINING CHROMIUM.

NOTE: A qualified welder must do the installation welding. The welder and welding procedure should be qualified in accordance with the ASME Boiler and Pressure Vessel Code Section IX or other applicable regulation.

CAUTION: To prevent damage to the seat and seals, do not allow the temperature of the seat and body seal area to exceed 94 $^{\circ}$ C (200 $^{\circ}$ F). It is recommended that thermal chalks be used to check the temperature in these areas during welding.

CAUTION: Ensure that any weld splatter does not fall onto the ball or seats. This may damage critical sealing surfaces and cause leaks.

The valve does not need to be disassembled before welding to the pipe. If the valve is disassembled, the body seals should be replaced.

Cycle the valve to the fully open position before welding.

Remove or protect the handle or actuator from weld splatter or arc strikes.

Before final welding, ensure a gap exists between the valve and end of the pipe in accordance with ASME welding standards. Tack weld the valve to the pipe in several locations and check for proper alignment with the pipe.

Weld by applying a 3 mm (1/8 inch) maximum weld bead per pass around each end. Use a temperature chalk and a wet cloth wrapped around the center section to prevent overheating.

For welds that require multiple passes to achieve final weld size, stop after each pass and carefully monitor the valve body temperature.

After welding, flush the pipeline with the valve in the fully open position to remove any weld splatter. Perform a visual inspection of the welds before next operation. Operate the valve 3 to 4 times to ensure proper operation of the valve.

3.3 VALVE INSULATION

Neles Easyflow ball valves do not require insulation. If desired, the valve may be insulated; however, the insulation must not continue above the upper level of the valve. See **Figure 2.**



Figure 2. Insulation of the valve

3.4 ACTUATOR

WARNING:

WHEN INSTALLING THE ACTUATOR ON THE VALVE, MAKE SURE THAT THE VALVE ASSEMBLY FUNCTIONS PROPERLY. INFORMATION ON ACTUATOR INSTALLATION IS GIVEN IN SECTION 7 OR IN THE SEPARATE ACTUATOR INSTRUCTIONS.

The actuator should be installed in a manner that allows plenty of room for its removal.

The actuator must not touch the pipeline, tanks, walls, or other equipment because vibration may interfere with its operation. Please ensure the stored energy in the actuator is released before installing the actuator up on the valve.

3.5 COMMISSIONING

Ensure that there is no dirt or foreign objects left inside the valve or pipeline. Flush the pipeline carefully. Make sure that the valve is fully open when flushing.

Ensure that all nuts, fittings, and cables are properly fastened.

If so equipped, check that the actuator positioner and/ or switch(s) are correctly adjusted. Actuator adjustment is in Section 5. To adjust any accompanying device(s) refer to the separate control equipment instruction manuals.

4. MAINTENANCE

4.1 GENERAL

Although Neles Easyflow valves are designed to work under severe conditions, proper preventative maintenance can significantly help to prevent unplanned downtime and reduce the total cost of ownership. Valmet recommends inspecting valves at least every five (5) years. The inspection and maintenance frequency depend on the actual application and process condition. Routine maintenance consists of tightening the gland flange bolts (item 16 in **exploded view**) periodically to compensate for stem seal wear.

Always loosen and tighten fasteners with the appropriate wrench to avoid damaging the valve, handle, linkage, actuator, fittings or flats.

Overhaul maintenance consists of replacing seats and seals. These parts may be obtained from Valmet or an Authorized Valmet Distributor.

WARNING:

FOR YOUR SAFETY, IT IS IMPORTANT THE FOLLOWING PRECAUTIONS BE TAKEN PRIOR TO REMOVAL OF THE VALVE FROM THE PIPELINE OR BEFORE ANY DISASSEMBLY:

- 1. BE SURE YOU KNOW WHAT FLUID IS IN THE PIPELINE. IF THERE IS ANY DOUBT, DOUBLE-CHECK WITH THE PROPER SUPERVISOR OR REFER RELEVANT APPROVED DOCUMENTS.
- 2. WEAR ANY PERSONAL PROTECTIVE EQUIPMENT (PROTECTIVE CLOTHING OR EQUIPMENT) REQUIRED WHEN WORKING WITH THE FLUID IS INVOLVED.
- 3. DEPRESSURIZE THE PIPELINE AND CYCLE THE VALVE AS FOLLOWS:
 - A. PLACE THE VALVE IN THE OPEN POSITION AND DRAIN THE PIPELINE.
 - B. CYCLE THE VALVE TO RELIEVE RESIDUAL PRESSURE IN THE BODY CAVITY BEFORE REMOVAL FROM THE PIPELINE
 - C. AFTER REMOVAL AND BEFORE DISASSEMBLY, CYCLE THE VALVE AGAIN SEVERAL TIMES.

4.2 ACTUATED VALVE

It is generally most convenient to detach the actuator and its auxiliary devices before removing the valve from the pipeline. If the valve package is small or if it is difficult to access, it may be more practical to remove the entire assembly.

NOTE: To ensure proper reassembly, observe the position of the actuator and positioner/limit switch with respect to the valve before detaching the actuator.

WARNING:

ALWAYS DISCONNECT THE ACTUATOR FROM ITS POWER SOURCE, PNEUMATIC, HYDRAULIC OR ELECTRICAL, BEFORE ATTEMPTING TO REMOVE IT FROM THE VALVE!

WARNING:

DO NOT REMOVE A SPRING-RETURN ACTUATOR UNLESS A STOP-SCREW IS CARRYING THE SPRING FORCE!

- 1. Detach the air supply, electrical supply, hydraulic supply and control signal cables or pipes from their connectors.
- 2. Remove the actuator mounting bracket screws.
- Lift the actuator straight up in line with the valve stem until the connection between actuator drive and valve stem is completely disengaged.
- 4. Place actuator in a safe location to avoid damage or personal injury.

4.3 VALVE DISASSEMBLY

<u>NOTE</u>: It is good practice to replace all seats and seals any time a valve is disassembled.

<u>NOTE</u>: Always use original OEM parts to make sure that the valve functions properly.

Numbers in () refer to items shown in the exploded view

- 1. Follow the steps in all the <u>WARNING</u> sections above before performing any work on the valve.
- 2. Open the valve.
- 3. Place the valve on a bench or other suitable working space.

- 4. Secure tank side flange to working surface to prevent movement during disassembly.
- 5. Remove body nuts (20).
- 6. Lift end pieces (2), body gaskets (18), seat retainers (17), and seats (4) from both ends of valve.
- 7. Close ball (3) by rotating stem (5) and lift ball (3) from body.
- Remove gland nuts (16), gland flange (14), disc spring (13), stem retainer 2 (10), v-ring stem seal (9), stem retainer 1 (8), and stem seal (7). Use caution to prevent denting or scratching the sealing surface inside the packing bore.
- 9. Push stem (5) into valve body and carefully remove. Avoid denting or scratching the sealing surface on the stem.
- 10. Remove bottom stem washer (6) from the body.

4.4 CHECKING PARTS

- 1. Clean all disassembled parts.
- 2. Check the stem (5) and ball (3) for damage. Pay particular attention to the sealing areas.
- 3. Check all sealing and gasket surfaces on the body (1) and end piece (2).
- 4. Replace any damaged parts.
- 5. Replace any fastener where the threads are damaged or have been heated, stretched or corroded.
- Replace any parts that have cracks, gouges or pits that will affect sealing.

NOTE: When ordering spare parts, always include the following information:

- a. Valve type code as per technical bulletin and model number from name plate,
- If the valve is serialized the serial number (stamped on the valve body or name plate) or applicable manufacturing order number,
- c. Spare part set number as per Table 3.

4.5 VALVE ASSEMBLY

Numbers in () refer to items shown in the **Exploded view**. It is advisable to replace seats and seals if complete disassembly and reassembly become necessary.

- 1. Clean all valve components, if not previously done.
- Inspect all components for damage before assembling the valve. Look for damage to the sealing areas on the ball, stem, and body.
- With a brush, clean body studs (19) and gland stud (15) of foreign material such as paint, thread locker, grime and commodity. Inspect the threads for damage or defect with appropriate ring or plug gage. Repair any out-of-tolerance threads or replace in-kind.
- Re-inspect all components for damage to the sealing areas, stem (5), body (1), and end piece (2). Replace any damaged parts.
- 5. Carefully clean and polish the ball (3) sealing surface: It should be free of all scratches and grooves.
- If the ball is slightly damaged, it may be possible to smooth the sealing surface with crocus cloth or equivalent. If deep scratches are present, replace the ball.
- 7. Place stem washer (6) over stem (5) and gently press into place against shoulder on stem (5).
- Insert the stem (5) into the body (1), being careful not to scratch the stem sealing surface; and press it gently up into the stem bore until resistance is felt from the stem washer (6).

- Holding stem (5) in place from the bottom, insert stem seal (7), stem retainer 1 (8), v-ring stem seal (9), and stem retainer 2 (10) with both inner and outer o-rings (11) and (12).
- 10. Install disc springs (13) (see **Figure 3** for proper orientation), gland flange (14), and gland flange nuts (16).
- Tighten gland nuts (16) evenly until stem seal (9) is compressed and then tighten an additional 1/4 turn. Visually inspect to ensure gland flange (14) is parallel with top of actuator mounting flange.



Figure 3. Proper Disc Spring Arrangement (uncompressed)

- Rotate the stem (5) so the ball drive is in the closed position. Place the ball (3) into the body cavity by partially rotating and sliding the ball onto the stem (5). Make certain the stem is roughly in the middle of the ball slot.
- Place the seats (4) and seat retainers (17) into the body (1) in the correct orientation so the proper surface contacts the ball.
- 14. Install the body gaskets (18) onto the end pieces (2).
- 15. Carefully place the end pieces (2) against the body (1) and loosely install the body studs (19) and nuts (20). Lightly lubricate stud threads and face of nut with anti-seize grease. Tighten the body nuts in an alternating sequence across the body, gradually increasing the tightening torque in multiple steps to applicable torque from **Table 1**.

Table 1				
Body Nut Tightening Torque, N.m				
Stud size	Carbon steel Grade B7	Stainless steel Grade B8M		
1/4 - 20 UNC	15	12		
5/16 - 18 UNC	30	25		
3/8 – 16 UNC	50	40		
7/16 – 14 UNC	75	65		
1/2 - 13 UNC	120	100		
9/16 – 12 UNC	160	150		
5/8 – 11 UNC	230	200		
3/4 - 10 UNC	400	370		
7/8 – 9 UNC	650	500		

- After fully tightening the stem seal and body joint flange, operate valve to verify smooth operation during opening and closing.
- 17. If the actuator was removed, reinstall and set the actuator stops as described in the **ACTUATOR MOUNTING INSTRUCTIONS** Section.

4.6 TESTING THE VALVE

WARNING:

WHEN PRESSURE TESTING, EXERCISE CAUTION AND MAKE SURE ALL EQUIPMENT USED IS IN GOOD WORKING CONDITION AND APPROPRIATE FOR THE INTENDED PRESSURE.

If the valve is to be tested prior to returning to service, make sure the test pressures are in accordance with an applicable standard.

When testing the valve for external tightness, keep the ball in the half open position.

If testing for seat tightness, please contact Valmet for advice.

WARNING:

WHEN PERFORMING ANY TESTS, NEVER EXCEED THE MAXIMUM OPERATING PRESSURE OR MAXIMUM SHUT-OFF PRESSURE LISTED ON THE name PLATE.

5. ACTUATOR

WARNING:

BEFORE INSTALLING THE VALVE AND ACTUATOR, BE SURE THAT THE INDICATOR POINTER ON TOP OF THE ACTUATOR IS CORRECTLY INDICATING THE VALVE POSITION. FAILURE TO ASSEMBLE THESE PRODUCTS TO INDICATE CORRECT VALVE POSITION COULD RESULT IN DAMAGE OR PERSONAL INJURY.

CAUTION:

When installing or servicing a valve/ actuator assembly, the best practice is to remove the entire assembly from service.

CAUTION:

An actuator should be remounted on the valve from which it was removed. The actuator must be checked and readjusted for proper open and close position each time it is remounted.

WARNING:

THE VALVE BODY AND MOUNTING INTERFACE HAS BEEN DESIGNED TO SUPPORT THE WEIGHT AND OPERATION OF Neles ACTUATORS AND RECOMMENDED ACCESSORIES. USE OF THIS INTERFACE TO SUPPORT ADDITIONAL EQUIPMENT SUCH AS PEOPLE, LADDERS, ETC. MAY RESULT IN THE FAILURE OF THE VALVE OR ACTUATOR AND MAY CAUSE PERSONAL INJURY.

WARNING:

BEWARE OF BALL MOVEMENT!

KEEP HANDS, OTHER PARTS OF THE BODY, TOOLS AND OTHER OBJECTS OUT OF THE OPEN FLOW PORT. LEAVE NO FOREIGN OBJECTS INSIDE THE VALVE OR PIPELINE. WHEN THE VALVE IS OPERATED, THE BALL FUNCTIONS AS A CUTTING DEVICE.

5.1 ACTUATOR MOUNTING INSTRUCTIONS

- When a spring-return actuator is being mounted, the valve should be in the closed position for spring-to-close operation or in the open position for the spring-to-open operation. When an electric or double-acting pneumatic actuator is being mounted, the valve position should correspond to the indicated actuator position.
- 2. Assemble actuator onto the valve, ensuring full engagement between the stem and actuator drive, and the actuator fully contacts the mounting face on the valve.
- 3. Tighten actuator mounting screws to the torque listed in **Table** below.

CAUTION:

Do not exceed the tightening torque. Applying excessive tightening torque can damage the threads in the actuator body.

TABLE 2				
Torque to Actuator bolting				
Bolt Size	No Lubrication to Screws			
mm	N.m			
M6	6.8			
M8	15			
M10	30			
M12	52			
M16	122			
M20	230			

 Cycle actuator and verify proper ball position in both open and closed positions. Adjust the actuator travel stops as necessary.

6. SERVICE / SPARE PART

We recommend that valves be directed to Valmet service centers for maintenance. The service centers are equipped to provide rapid turn-around at a reasonable cost and offer warranty for reconditioning based on condition of each valve.

NOTE: When sending goods to the service center for repair, do not disassemble them. Clean the valve carefully and flush the valve internals. Include the material safety datasheet(s) (MSDS) for all media flowing through the valve. Valves sent to the service center without MSDS datasheet(s) will not be accepted.

For further information on spare parts and service or assistance visit our web-site at **www.neles.com/products**.

NOTE: When ordering spare parts, always include the following information:

- a. Valve type code as per technical bulletin and model number from name plate,
- b. If the valve is serialized the serial number (stamped on the valve body or name plate) or applicable manufacturing order number,

*Sign.1	Sign.2	Sign.3	*Sign.4	#Sign.5	Spare part sets
Valve size	Series	Seat and seal materials	O-Ring material	Flow bore	Type codes
15	J4	ZG	53	NA	15 J4ZG53
20		(TEM™ 1600 /	(Fluoroelastomer	NA	20 J4ZG53
25		Graphite)	- FKM)	NA	25 J4ZG53
32				NA	32 J4ZG53
40				A = Reduced bore	40 J4ZG53 A
				B = Full bore	40 J4ZG53 B
50				A = Reduced bore	50 J4ZG53 A
				B = Full bore	50 J4ZG53 B

c. Spare part set number as per Table 3.

* leave space after Sign.1 and Sign.4

NA – Not applicable (both full bore and reduced bore have same spare part set). # Sign.5 suffix A and B applicable for DN 40 and DN 50 valve sizes e.g. 25 J4ZG53, 40 J4ZG53 B, etc.

7. WELDING WARNING

WARNING:

WELDING AND/OR GRINDING OF STAINLESS STEEL AND OTHER ALLOY STEELS CONTAINING CHROMIUM METAL MAY CAUSE THE RELEASE HEXAVALENT CHROMIUM. HEXAVALENT CHROMIUM, CHROMIUM(VI) OR CR(VI), IS KNOWN TO CAUSE CANCER. BE SURE TO USE ALL APPROPRIATE PPE WHEN WELDING METALS CONTAINING CHROMIUM. IF YOU HAVE ANY QUESTIONS CONSULT YOUR SUPERVISOR.

8. EXPLODED VIEW DN15 TO DN5



Figure 4.

9. EU DECLARATION OF CONFORMITY FOR ATEX APPROVED VALVES

		for ATEX approved valves		
Manufactu Valmet Flo E-61, Addi 421506 Ar Maharashi	rer: ww Control Private L tional MIDC Area, A nbernath (East) ira, India	imited Anand Nagar,		(Ex)
EU Authoris Vantaa, Fin	sed Representative: V land. Contact details:	almet Flow Control Oy, Vanha Porvoontie 2 <u>+358 10 417 5000</u>	29, 01380	
<u>his declara</u> Product:	tion of conformity is is Neles Easyflow Ba	sued under the sole responsibility of the ma Il valves	nufacturer.	
Type:	J4-, J7- and J9-ser	ies		
	ATEX group and c Ex GAS: Ex DUST:	eategory: E II 2 GD, II 3 GD Ex h IIC 85°CTmax Gb/Gc Ex h IIIC T85°CT(Tmax) Db/Dc	Tmax= va	lve max, temperature in name plate
1				
<u>Manufacture</u> Stondord / F	er's certificates:	Notified Pody and NoPo number		Cortificato No
SO 9001-20)15	I RQA (Certification Body)		10531829
PED 2014/6	8/EU Module H	DNV Business Assurance Italy S r I 0	496	142306-2013-CE-FIN-ACCREDIA
ATEX 2014	34/EU Annex IV	DNV Product Assurance AS Norway	2460	Presafe 18 ATEX 91983Q Issue 6
ATEX 2014/	'34/EU Annex VIII tec	nnical files are archived by Notified Body nu	mber 0537	
ATEX 2014/ <u>The object c</u> PED 2014/ <u>ATEX 201</u> /	34/EU Annex VIII tec of the declaration deso 68/EU 4/34/EU	nnical files are archived by Notified Body nu cribed above is in conformity with the relevar Va No	mber 0537 ht Union harr alve on-electrical	monisation legislation: equipment
The object of PED 2014/ ATEX 2014/ ATEX 2017/ Main compo Valve: The valve i Valve desig	34/EU Annex VIII tec of the declaration desc 68/EU 4/34/EU nents: s suitable for service of gn standard: ASME B	nnical files are archived by Notified Body nu cribed above is in conformity with the relevar Va No No up to PED Cat III 16.34	mber 0537 <u>nt Union harr</u> alve on-electrical	monisation legislation: equipment
ATEX 2014/ PED 2014/ ATEX 2014/ ATEX 2014/ Main compo Valve: The valve i Valve desig Installation, mounting an The product	34/EU Annex VIII tec of the declaration desc 68/EU 4/34/EU ments: s suitable for service of gn standard: ASME B Maintenance and Operat d usage of equipment. above is manufactured i	nnical files are archived by Notified Body nu cribed above is in conformity with the relevar Va No up to PED Cat III 16.34 ing instructions manual (IMO) must be followed b n compliance with the applicable European direct	mber 0537 nt Union ham alve on-electrical efore installat ives and techn	monisation legislation: equipment ion in order to ensure proper and safe nical specifications/standards EN10204.
ATEX 2014/ The object of PED 2014/ ATEX 2014/ Main compo Valve: The valve i Valve desig Installation, i mounting an The product The product	34/EU Annex VIII tec of the declaration desc (68/EU 4/34/EU nents: s suitable for service i gn standard: ASME B Maintenance and Opera d usage of equipment. above is manufactured i is in conformity with the	nnical files are archived by Notified Body nu cribed above is in conformity with the relevar Va No up to PED Cat III 16.34 ing instructions manual (IMO) must be followed b n compliance with the applicable European direct customer order.	mber 0537 <u>at Union harr</u> alve <u>on-electrical</u> efore installat ives and techn	monisation legislation: equipment ion in order to ensure proper and safe nical specifications/standards EN10204.
ATEX 2014/ The object of PED 2014/ ATEX 201- Main compo Valve: The valve i Valve desig Installation, i mounting an The product The product Instrumental be in conform	34/EU Annex VIII tec of the declaration desc 68/EU 4/34/EU nents: s suitable for service i gn standard: ASME B Maintenance and Operai d usage of equipment. above is manufactured i is in conformity with the ion and accessories hav nity with this Declaration	nnical files are archived by Notified Body numerical files are archived by Notified Body numerical files are archived by Notified Body numerical files are archived by Notified above is in conformity with the relevant of Conformity.	mber 0537 <u>at Union harr</u> alve <u>on-electrical</u> efore installat ives and techn ace specification	monisation legislation: equipment ion in order to ensure proper and safe nical specifications/standards EN10204. on with the original can be presumed to
ATEX 2014/ PED 2014/ ATEX 2014/ ATEX 2014/ ATEX 2014/ Main compo Valve: The valve i Valve desig Installation, I mounting an The product Instrumental be in conforn Protection fr EN 60079-11	34/EU Annex VIII tec of the declaration desc (68/EU 4/34/EU nents: s suitable for service of gn standard: ASME B Maintenance and Operat d usage of equipment. above is manufactured i is in conformity with the ion and accessories hav nity with this Declaration om e.g. static electricity 9 applies for modification	nnical files are archived by Notified Body numerical files are archived by Notified Body numerical files are archived by Notified Body numerical files and conformity with the relevant Value of the PED Cat III 16.34 In the period of the second of the sec	mber 0537 <u>at Union harr</u> alve <u>on-electrical</u> efore installat ives and technologies and technologies ace specification	monisation legislation: equipment ion in order to ensure proper and safe nical specifications/standards EN10204. on with the original can be presumed to lered by the user (EN 60079-14 § 6).
ATEX 2014/ The object of PED 2014/ ATEX 201- Main compo Valve: The valve i Valve desig Installation, i mounting an The product The product Instrumental be in conform Protection fr EN 60079-11 Non-electric: equipment is temperature	34/EU Annex VIII tec of the declaration desc (68/EU 4/34/EU nents: s suitable for service of gn standard: ASME B Maintenance and Operal d usage of equipment. above is manufactured i is in conformity with the ion and accessories hav mity with this Declaration om e.g. static electricity of applies for modification al equipment is accordin a depended on the proce must be considered by f	nnical files are archived by Notified Body numerical files are archived by Notified Body numerical files are archived by Notified Body numerical files and ambient conditions (EN 80079-36:2016 § of the end user before put into service.	mber 0537 <u>at Union harr</u> alve <u>on-electrical</u> efore installat ives and techn ives and techn ince specification nust be consid e actual surfac 6.2.5 and 6.2.	monisation legislation: equipment ion in order to ensure proper and safe nical specifications/standards EN10204. on with the original can be presumed to lered by the user (EN 60079-14 § 6). se temperature of non-electrical 7). The protection from high or low
ATEX 2014/ The object of PED 2014/ ATEX 2014/ ATEX 2014/ Main compoon Valve: The valve in Valve design Installation, in mounting an The product Instrumental be in conform Protection for Protection for Protection for EN 60079-11: Non-electric: equipment is temperature The product procedures s	34/EU Annex VIII tec of the declaration desc 68/EU 4/34/EU ments: s suitable for service of gn standard: ASME B Maintenance and Operat d usage of equipment. above is manufactured i is in conformity with the ion and accessories hav mity with this Declaration or e.g. static electricity of applies for modification al equipment is accordin of depended on the proce must be considered by the does not possess any re- stated by the IMO are fol	nnical files are archived by Notified Body numerical files are archived by Notified Body numerical files are archived by Notified Body numerical files and conformity with the relevant Value of PED Cat III 16.34 In orphiance with the applicable European direct for a compliance with the applicable European direct for a conformity. In a compliance with the applicable European direct for a conformity. In a compliance with the applicable European direct for a conformity. In a compliance with the applicable European direct for a conformity. In a compliance with the applicable European direct for a conformity. In a compliance with the applicable European direct for a conformity. In a compliance with the applicable European direct for a conformity. In a compliance with the applicable European direct for a conformity. In a compliance with the applicable European direct for a conformity. In a compliance with the applicable European direct for a conformity. In a compliance with the applicable European direct for a conformity. In a conformity is a conformity of the and the product is used under conditions methods and the product is used under conditions and the	mber 0537 <u>at Union harr</u> alve <u>on-electrical</u> efore installat ives and techr nues pecification nust be consid e actual surface 6.2.5 and 6.2. ed under the a nentioned in th	monisation legislation: equipment ion in order to ensure proper and safe nical specifications/standards EN10204. on with the original can be presumed to lered by the user (EN 60079-14 § 6). the temperature of non-electrical 7). The protection from high or low upplicable directives providing that the the technical specifications.
ATEX 2014/ The object of PED 2014/ ATEX 2014/ ATEX 2014/ ATEX 2014/ Main compoon Valve: The valve i Valve design Installation, I mounting an The product Instrumentate be in conforr Protection fr EN 60079-11 Non-electrical equipment is temperature The product procedures so Documents of national cod dispatch the documents i predefined a	34/EU Annex VIII tec of the declaration desc 68/EU 4/34/EU inents: s suitable for service of gn standard: ASME B Maintenance and Operat d usage of equipment. above is manufactured i is in conformity with the ion and accessories hav nity with this Declaration op e.g. static electricity applies for modification al equipment is accordin is depended on the proce must be considered by the does not possess any re stated by the IMO are fol with digital and/or e-sign e on e-signatures. In ord identification is covered s based on organizationa uthorities to particular da	Inical files are archived by Notified Body number pribed above is in conformity with the relevar Van Note	mber 0537 <u>at Union harr</u> <u>alve</u> <u>on-electrical</u> efore installat ives and techr ace specification ust be consid a actual surface 6.2.5 and 6.2. ed under the a nentioned in the henticity of the henticity of the ity changing p d party in the	monisation legislation: equipment ion in order to ensure proper and safe nical specifications/standards EN10204. on with the original can be presumed to lered by the user (EN 60079-14 § 6). the temperature of non-electrical 7). The protection from high or low upplicable directives providing that the te technical specifications. ion (EU) No 910/2014 as well as the e sender, and indisputableness of the passwords. The authorization to sign company bestows the access right with
ITEX 2014/ The object of PED 2014/ ATEX 2014/ ATEX 2014/ ATEX 2014/ Installation, I mounting an The valve design Installation, I mounting an The product Instrumental be in conforr Protection fr EN 60079-19 Non-electric: equipment is temperature The product procedures s Documents i predefined a	34/EU Annex VIII tec of the declaration desc (68/EU 4/34/EU nents: s suitable for service of gn standard: ASME B Maintenance and Operal d usage of equipment. above is manufactured i is in conformity with the ion and accessories hav mity with this Declaration om e.g. static electricity of applies for modification al equipment is accordin depended on the proce must be considered by for does not possess any re stated by the IMO are for with digital and/or e-sign e on e-signatures. In ord identification is covered s based on organizationa uthorities to particular da	Inical files are archived by Notified Body numerical files are archived by Notified Body numerical files are archived by Notified Body numerical files are archived by with the relevant of the second structure of the second	mber 0537 <u>at Union harr</u> <u>alve</u> <u>on-electrical</u> efore installat ives and techn use specification use be consid e actual surface 6.2.5 and 6.2. ad under the a thenticity of the rity changing p d party in the	monisation legislation: equipment ion in order to ensure proper and safe nical specifications/standards EN10204. on with the original can be presumed to lered by the user (EN 60079-14 § 6). ce temperature of non-electrical 7). The protection from high or low upplicable directives providing that the the technical specifications. ion (EU) No 910/2014 as well as the e sender, and indisputableness of the basswords. The authorization to sign company bestows the access right with

10. TYPE CODE

NELES EASYFLOW J4 3-PIECE SEAT SUPPORTED BALL VALVE

1.	2.	3.	4.	5.	6.	7.	8.	9.	10.
50	J4	В	N	22	36	36	ZG	53	

1.	Size, DN (NPS ref.)
15	15 (1/2)
20	20 (3/4)
25	25 (1)
32	32 (1 1/4)
40	40 (1 1/2)
50	50 (2)

6.	Ball material
36	316 Stainless steel
7.	Stem material
36	316 Stainless steel
43	17-4PH Stainless steel
8.	Seat and seal materials
ZG	TFM™ 1600 / Graphite
VG	Devlon® / Graphite
9.	O-Ring material
53	Fluoroelastomer (FKM)
10.	Options
	Blank, standard option
Q	Cavity filler seat

3.	Flow bore
А	Reduced bore
В	Full bore

4.	End connection
N	NPT
В	BSP
S	Socket weld end
Т	Butt weld end Sch. 40 or 40S as applicable

5.	Body material
22	Carbon steel (WCB)
36	Stainless steel (CF8M)*

* End pieces are dual certified with CF3M for weld end valves

TFM[™] is a trademark of Dyneon, a 3M Company

Devlon® is a registered trademark of James Walker Sealing Products & Services Ltd

NOTE:

2.

J4

Series

As the use of the valve is application specific, a number of factors should be taken into account when selecting a valve for a given application.

Therefore, some of the applications in which the valves are used are outside the scope of this document.

If you have any questions concerning the use, application or compatibility of the valve with the intended service, contact nearest Valmet sales office for more information.

11. GENERAL SAFETY WARNINGS AND DISCLAIMERS

General safety warnings

Lifting

- Always use a lifting plan created by a qualified person to lift this equipment. Lifting guidance is provided in this IMO (Installation, Maintenance and Operation manual) to assist in lifting plan development. Think about the center of gravity (CG) of the equipment being lifted. Make sure the CG is always under the central lifting point.
- Valves may be equipped with lifting threads on the body or on the flanges. These are intended to be used with the lifting plan.
- Use only correct and approved lifting devices. Ensure that lifting devices and straps are securely attached to the equipment prior to lifting.
- 4. Check, that lifting devices are not damaged and in good condition with a valid check stamp prior to use.
- 5. Workers must be trained for lifting and handling valves.
- 6. Never lift an assembly by the instrumentation (solenoid, positioner, limit switch, etc.) or by the instrumentation piping. Straps and lifting devices should be fitted to prevent damage to instrumentation and instrumentation piping. Failure to follow the lifting guidance provided may result in damage and personal injury from falling objects.

Work activities on the valve

- Wear your personal safety equipment. Personal safety equipment includes but is not limited to protective shoes, protective clothing, safety glasses, helmet, hearing protection and working gloves.
- Always follow the local safety instructions in addition to the Valmet instructions. If Valmet instructions conflict with local safety instructions, stop work and contact Valmet for more information.
- 3. Before beginning service on the equipment, make sure that the actuator is disconnected from any kind of power source (pneumatic, hydraulic, and/or electric), and no stored energy is applied on the actuator (compressed spring, compressed air volumes, etc.). Do not attempt to remove a spring return actuator unless the stop screw is carrying the spring force.
- Make sure that there is a LOTOTO (Lock Out / Tag Out / Try Out) procedure in place for the system in which the valve is installed and strictly follow it.
- Always make sure that the pipeline is depressurized and in ambient temperature condition before maintenance work is started.
- 6. Keep hands and other body parts out of the flow port when the valve is being serviced and the actuator is connected to the valve. There is a high risk of serious injury to hands and/ or fingers due to malfunction if the valve suddenly starts to operate.
- 7. Beware of Trim (Disc, Ball or Plug) movement even when the valve is disassembled. Trim may move simply due to the weight of the part or change in position of the valve. Keep hands or other body parts away from locations where they may be injured by movement of the trim. Do not leave objects near or in the valve port which may fall in and need to be retrieved.

General disclaimers

Receiving, handling and unpacking.

- 1. Respect the safety warnings above!
- 2. Valves are critical components for pipelines to control high pressure fluids and must therefore be handled with care.

- 3. Store valves and equipment in a dry and protected area until the equipment is installed.
- 4. Do not exceed the maximum storage temperatures given in the IMO (installation, maintenance, and operating instructions).
- 5. Keep the original packaging on the valve as long as possible to avoid environmental contamination by dust, water, dirt, etc.
- 6. Remove the valve endcaps just before mounting into the pipeline.
- 7. FOR YOUR SAFETY IT IS IMPORTANT TO FOLLOW THESE PRECAUTIONS BEFORE REMOVAL OF THE VALVE FROM THE PIPELINE OR ANY DISASSEMBLY:
 - Be sure you know what flow medium is in the pipeline. If there is any doubt, confirm with the proper supervisor.
 - Wear any personal protective equipment (PPE) required for working with the flow medium involved in addition to any other PPE normally required.
 - Depressurize the pipeline, bring to ambient temperature, and drain the pipeline flow medium.
 - Cycle the valve to relieve any residual pressure in the body cavity.
 - After removal but before disassembly, cycle the valve again until no evidence of trapped pressure remains.
 - The valves with offset shaft (Butterfly, eccentric rotary plug) have greater trim area on one side of the shaft. This will cause the valve to open when pressurized from the preferred direction without a locking handle or an actuator installed.
 - WARNING: DO NOT PRESSURIZE THE ECCENTRIC VALVE WITHOUT A HANDLE OR AN ACTUATOR MOUNTED ON IT!
 - WARNING: DO NOT REMOVE A HANDLE OR AN ACTUATOR FROM AN ECCENTRIC VALVE WHILE PRESSURIZED!
 - Before installing the eccentric valve in or remove it from the pipeline, cycle the valve closed. Eccentric valves must be in the closed position to bring the trim within the face to face of the valve. Failure to follow these instructions will cause damage to the valve and may result in personal injury.

Operating

- 8. The identification plate (ID-plate, type plate, nameplate, or engraved markings) on the valve gives the information of max. process conditions to the valve.
- 9. (For soft seats) The practical and safe use of this product is determined by both the temperature and pressure ratings of the seat and body. Read the identification plate and check both ratings. This product is available with a variety of seat materials. Some seat materials have pressure ratings that are lower than the body ratings. All body and seat ratings are dependent on the valve type, size and material of the body and seat. Never exceed the marked rating.
- Temperatures and pressures must never exceed values marked on the valve. Exceeding these values may cause uncontrolled release of pressure and process medium. Damage or personal injury may result.
- 11. The operating torque of the valve may rise over time due to wear, particles or other damage of the seat. Never exceed the actuator torque preset values (air supply, position). Application of excessive torque may cause damage to the valve.
- Valmet valves typically are designed to be used in atmospheric conditions. Do not use valves under external pressurized conditions unless specifically designed and explicitly marked for this service.

- 13. Avoid Pressure shocks or water hammer. Systems with high pressure valves should be equipped with a bypass to reduce the differential pressure before opening the valve to avoid pressure shock.
- 14. Avoid thermal shock. High temperature, Low temperature and cryogenic valves should be operated in a way that limits the rate of increase or decrease in temperature. The valve should be thermally stabilized before being pressurized.
- 15. Materials of the valve are carefully selected for the process conditions. Changes to the process media can have a major impact on function and safety of the valve. Always confirm the materials are suitable for the service prior to installation.
- 16. As the use of the valve is application specific, several factors should be considered when selecting a valve for a given application. Therefore, some situations in which the valves are used are outside the scope of this manual.
- 17. It is the end user's responsibility to confirm compatibility of the valve materials with the intended service, however if you have questions concerning the use, application, or compatibility of the valve for the intended service, contact Valmet for more information.
- 18. Never use a valve with enriched or pure oxygen if the valve is not explicitly designed and cleaned for oxygen. Selected materials and design have a major impact on the safety to operate the valve with oxygen.
- Valves intended for use in or with explosive atmospheres must be equipped with a grounding device and marked according ATEX (or equivalent international standards).
- 20. Manual handles are available for specific butterfly valve sizes and maximum line pressures. Do not operate a valve with a handle or wrench outside the size and pressure limits stated in the IMO. High line pressure may create a large enough force to pull the handle from the operator's hands. Damage or personal injury may result.

Maintenance

- 21. Respect the safety warnings above!
- 22. Plan service and maintenance actions, that spare parts, lifting devices and service personnel is available.
- 23. Maintain the valve within the recommended minimum maintenance intervals or within the recommended maximum operating cycles.
- 24. Always make sure that the valve and the pipeline is depressurized before starting any kind of maintenance work at a valve.
- 25. Always check the position of the valve before starting maintenance work. Follow the Lock out /tag out (LOTO) rules at the site before starting any maintenance activity.
 - See IMO for the correct stem position.
 - Consider that the positioner may give the wrong signals.
- 26. Sealing materials (soft sealing parts) should be changed when the valve is in maintenance. Always use original equipment manufacturers (OEM) spare parts to ensure proper performance of the repaired valve.
- 27. All pressure containing parts must be inspected visually for damage or corrosion. Damaged parts must be replaced.
- 28. Valve pressure retaining parts and all internals must be inspected for corrosion or erosion which may result in reduced wall thickness on pressure retaining parts. Damaged pressure retaining parts must be replaced with original equipment manufacturer's (OEM) replacement parts or repaired to factory specifications by an authorized Valmet service partner in order to maintain the warranty.

- 29. Do not use sharp tools, grinding machines, or files to work on functional surfaces such as sealing, seating or bearing surfaces as this can damage these surfaces.
- Check the condition of sealing surfaces on the seats, trim (disc, ball, plug, etc.), body and body cap. Replace parts if there are significant wear, scratches, or damage.
- 31. Check the wear of bearings and bearing contact surfaces on the shaft and replace damaged parts if necessary.
- 32. Do not weld on pressure retaining parts without an ASME and PED qualified procedure and personnel.
- Pressure retaining parts of valves in high temperature applications must be carefully examined for the effects of material creep and fatigue.
- 34. Make sure that the valve is positioned in the correct flow direction into the pipeline.
- 35. If the valves are marked to be suitable for explosive atmospheres, the correct function of the discharging device must be tested before returning to service.
- 36. Always work in a clean environment. Avoid getting particles inside the valve due to machining, grinding, or welding nearby.
- 37. Never store a valve in maintenance without flow port protection.
- 38. When pressure testing valve seats, never exceed the maximum operating pressure of the system or the maximum shut- off pressure marked on the valve identification plate.
- 39. Actuator mounting and unmounting:
 - Before installing the actuator on to the valve, be sure the actuator is properly indicating the valve position. Failure to assemble these to indicate correct valve position may result in damage or personal injury.
 - When installing or removing a linkage kit, best practice is to remove the entire linkage assembly, including couplings which may fall off the valve during lifting or when position changes.
 - Mounting sets have been designed to support the weight of the Valmet actuator and recommended accessories either as is or with additional actuator support. Use of the linkage to support additional equipment or additional weight such as people, ladders, etc. may result in equipment damage or personal injury.
- 40. The valve should be installed between flanges using appropriate gaskets and fasteners that are compatible with the application, and in compliance with applicable piping codes and standards. Center the gaskets carefully when fitting the valve between the flanges. Do not attempt to correct pipeline misalignment by means of the flange bolting.
- 41. Repairs on valves for special service like Oxygen, Chlorine, and Peroxide, have special requirements.
 - Parts must be cleaned appropriate to the service and protected from contamination prior to assembly.
 - Assembly areas and tools must be clean and dry to prevent contamination of the parts during assembly.
 - Test equipment must be clean and dry to prevent contamination during testing. This includes the test equipment internals that may allow particles or other contamination into the test medium during the test.
 - Lubrication shall be used only if specifically required in the instructions. Where lubrication is required, the lubricant must be approved for the service by the end user.

Valmet Flow Control Oy

Vanha Porvoontie 229, 01380 Vantaa, Finland. Tel. +358 10 417 5000. www.valmet.com/flowcontrol

