

# Neles Easyflow™

JA series concentric disc  
resilient seated butterfly valves  
DN50 - DN600 (2" - 24")

Installation, maintenance and  
operating instructions



# Table of contents

<b>GENERAL</b>	<b>4</b>	<b>SERVICE / SPARE PART</b>	<b>13</b>
Scope of the Manual	4	<b>WELDING WARNING</b>	<b>13</b>
Body end connections	4	<b>EXPLODED VIEW</b>	<b>15</b>
Valve Markings	4	<b>EU DECLARATION OF CONFORMITY FOR ATEX APPROVED VALVES</b>	<b>16</b>
Safety Precautions	4	<b>TYPE CODE</b>	<b>17</b>
CE and ATEX marking	4	<b>NELES EASYFLOW JA SERIES BUTTERFLY VALVE</b>	<b>17</b>
<b>TRANSPORTATION AND STORAGE</b>	<b>5</b>	<b>HOW TO ORDER</b>	<b>17</b>
<b>INSTALLATION</b>	<b>5</b>	<b>GENERAL SAFETY WARNINGS AND DISCLAIMERS</b>	<b>18</b>
General	5	General safety warnings	18
Installing in the Pipeline	5	General disclaimers	18
Flange bolt size and length tables	6		
Wafer body & lug body	7		
Flange bolt tightening torque	10		
Operation and Actuator	10		
Commissioning	10		
<b>MAINTENANCE</b>	<b>10</b>		
General	10		
Actuated Valve	10		
Valve Removal	11		
Valve Disassembly	11		
Checking Parts	11		
Valve Assembly	11		
Testing the Valve	12		
<b>ACTUATOR</b>	<b>12</b>		
Actuator Mounting Instructions	13		

## READ THESE INSTRUCTIONS FIRST!

These instructions provide information about safe handling and operation of the valve.

If you require additional assistance, please contact the manufacturer or manufacturer's representative.

## SAVE THESE INSTRUCTIONS!

Addresses and phone numbers are printed on the back cover.

## JA Series Easyflow by Neles™ resilient seated butterfly valve

THESE INSTRUCTIONS PROVIDE THE CUSTOMER/OPERATOR WITH IMPORTANT INFORMATION IN ADDITION TO THE CUSTOMER/OPERATOR'S NORMAL OPERATION AND MAINTENANCE PROCEDURES. SINCE OPERATION AND MAINTENANCE PHILOSOPHIES VARY, VALMET DOES NOT ATTEMPT TO DICTATE SPECIFIC PROCEDURES, BUT TO PROVIDE BASIC LIMITATIONS AND REQUIREMENTS CREATED BY THE TYPE OF EQUIPMENT PROVIDED.

THESE INSTRUCTIONS ASSUME THAT OPERATORS ALREADY HAVE A GENERAL UNDERSTANDING OF THE REQUIREMENTS FOR SAFE OPERATION OF MECHANICAL AND ELECTRICAL EQUIPMENT IN POTENTIALLY HAZARDOUS ENVIRONMENTS. THEREFORE, THESE INSTRUCTIONS SHOULD BE INTERPRETED AND APPLIED IN CONJUNCTION WITH THE SAFETY RULES AND REGULATIONS APPLICABLE AT THE SITE AND THE PARTICULAR REQUIREMENTS FOR OPERATION OF OTHER EQUIPMENT AT THE SITE.

THESE INSTRUCTIONS DO NOT INTEND TO COVER ALL DETAILS OR VARIATIONS IN EQUIPMENT NOR TO PROVIDE FOR EVERY POSSIBLE CONTINGENCY TO BE MET IN CONNECTION WITH INSTALLATION, OPERATION OR MAINTENANCE. SHOULD FURTHER INFORMATION BE DESIRED OR SHOULD PARTICULAR PROBLEMS ARISE WHICH ARE NOT COVERED SUFFICIENTLY FOR THE CUSTOMER/ OPERATOR'S PURPOSES THE MATTER SHOULD BE REFERRED TO VALMET.

THE RIGHTS, OBLIGATIONS AND LIABILITIES OF VALMET AND THE CUSTOMER/OPERATOR ARE STRICTLY LIMITED TO THOSE EXPRESSLY PROVIDED IN THE CONTRACT RELATING TO THE SUPPLY OF THE EQUIPMENT. NO ADDITIONAL REPRESENTATIONS OR WARRANTIES BY VALMET REGARDING THE EQUIPMENT OR ITS USE ARE GIVEN OR IMPLIED BY THE ISSUE OF THESE INSTRUCTIONS.

THESE INSTRUCTIONS CONTAIN PROPRIETARY INFORMATION OF VALMET AND ARE FURNISHED TO THE CUSTOMER/ OPERATOR SOLELY TO ASSIST IN THE INSTALLATION, TESTING, OPERATION, AND/OR MAINTENANCE OF THE EQUIPMENT DESCRIBED. THIS DOCUMENT SHALL NOT BE REPRODUCED IN WHOLE OR IN PART NOR SHALL ITS CONTENTS BE DISCLOSED TO ANY THIRD PARTY WITHOUT THE WRITTEN APPROVAL OF VALMET.

# 1. GENERAL

## 1.1 SCOPE OF THE MANUAL

This instruction manual contains important information regarding the installation, operation and maintenance of Neles™ Easyflow™ JA series concentric disc resilient seated butterfly valves. Please read these instructions carefully and save them for future reference.

### WARNING:

THE USE OF THE VALVE IS APPLICATION SPECIFIC. BE SURE THAT THE VALVE IS SUITABLE FOR ITS INTENDED SERVICE. IF YOU HAVE ANY QUESTIONS CONCERNING THE USE, APPLICATION OR COMPATIBILITY OF THE VALVE WITH THE INTENDED SERVICE, CONTACT VALMET FOR MORE INFORMATION.

### WARNING:

IF THE VALVE DOES NOT HAVE A HANDLE OR AN ACTUATOR DO NOT PRESSURIZE. UNRESTRAINED DISC MAY OPEN OR CLOSE DUE TO PIPELINE PRESSURE.

## 1.2 BODY END CONNECTIONS

The JA series valve comes with either wafer or lug end connections. Some wafer designs contain flange bolt holes or slots in the body to hold the valve and assist with correct alignment with the flange during installation in the line. The centering holes or slots in wafer bodies alone are not suitable, or intended for containing line pressure, and are for use in conjunction with a fully bolted pipeline flange.

### WARNING:

WAFFER STYLE BODY BUTTERFLY VALVES MUST BE INSTALLED WITH A FLANGE ATTACHED TO THE DOWNSTREAM SIDE OF THE VALVE FOR DEAD-END OR END OF PIPELINE SERVICE. INSTALLING WAFFER STYLE BODY BUTTERFLY VALVES AT THE END OF A PIPELINE WITHOUT ANY DOWNSTREAM PIPING OR FLANGES COULD LEAD TO UNCONTROLLED RELEASE OF PRESSURE, DAMAGE, OR PERSONAL INJURY!

The lug end valve is intended to be fastened to the flanges with the threaded lugs.

## 1.3 VALVE MARKINGS

The valve has a label plate attached to the valve body (see **Figure 6**). The label plate markings identify the size, materials of construction, pressure rating, month and year of construction, and a unique serial and manufacturing order number for the valve.

## 1.4 SAFETY PRECAUTIONS

### WARNING:

DO NOT EXCEED THE VALVE PERFORMANCE LIMITATIONS! EXCEEDING THE PRESSURE OR TEMPERATURE LIMITATIONS MARKED ON THE VALVE LABEL PLATE MAY CAUSE DAMAGE AND LEAD TO UNCONTROLLED PRESSURE RELEASE. MAY RESULT IN DAMAGE OR PERSONAL INJURY

### WARNING:

#### SEAT AND BODY RATINGS!

THE PRACTICAL AND SAFE USE OF THIS PRODUCT IS DETERMINED BY BOTH THE SEAL AND BODY RATINGS. READ THE LABEL PLATE. THE BODY AND TEMPERATURE RATINGS ARE DEPENDENT ON VALVE TYPE AND SEAL MATERIAL. DO NOT EXCEED THESE RATINGS!

### WARNING:

#### BEWARE OF DISC MOVEMENT!

KEEP HANDS, OTHER PARTS OF THE BODY, TOOLS AND OTHER OBJECTS OUT OF THE OPEN FLOW PORT. LEAVE NO FOREIGN OBJECTS INSIDE THE PIPELINE. WHEN THE VALVE IS ACTUATED, THE DISC FUNCTIONS AS A CUTTING DEVICE. DISCONNECT ANY PNEUMATIC SUPPLY LINES, ANY ELECTRICAL POWER SOURCES AND MAKE SURE SPRINGS IN SPRING-RETURN ACTUATORS ARE IN THE FULL EXTENDED/RELAXED STATE BEFORE PERFORMING ANY VALVE MAINTENANCE. VALVE DISC IS KEPT IN CRACK OPEN POSITION PRIOR TO DISPATCH, SO THAT SEAL REMAINS IN UN-STRESSED CONDITION. FAILURE TO DO THIS MAY RESULT IN DAMAGE OR PERSONAL INJURY!

### WARNING:

#### WHEN HANDLING THE VALVE OR VALVE/ACTUATOR ASSEMBLY, TAKE ITS WEIGHT INTO ACCOUNT!

NEVER LIFT THE VALVE OR VALVE/ACTUATOR ASSEMBLY BY THE ACTUATOR, POSITIONER, LIMIT SWITCH OR THEIR PIPING. PLACE LIFTING DEVICES SECURELY AROUND THE VALVE BODY. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY RESULT IN DAMAGE OR PERSONAL INJURY FROM FALLING PARTS (SEE **FIGURE 1**).

## ATEX/Ex safety

### CAUTION:

Potential electrostatic hazard, ensure the protection (grounding, etc.) in the process.

### CAUTION:

The actual surface temperature of valve is depended on the process temperature. The protection from high or low temperature must be considered by the end user before valve is put into service.

### CAUTION:

Ensure the general process and worker protection from static electricity in the facilities.

## 1.5 CE AND ATEX MARKING

The valve meets the requirements of the European Directive 2014/68/EU relating to pressure equipment, and has been marked according to the Directive.

When applicable, the valve meets the requirements of the European Directive 2014/34/EU relating to equipment and protective systems intended for use in potentially explosive atmosphere, and has been marked according to the Directive.

## 2. TRANSPORTATION AND STORAGE

1. Check the valve and the accompanying devices for any damage that may have occurred during transport.
2. Store the valve carefully. Storage indoors in a cool, dry place. Less than 65% humidity is recommended.
3. Avoid direct exposure to sunlight.
4. The valve is delivered with the disc partially open about 10 degrees, and it should remain in this position during storage.
5. A light coating of Silicone grease is applied to the edge of the disc before packing at the factory. Do not remove valve from packaging until installation to protect from potentially harmful effects like dust and moisture. Do not leave valve unpacked for long periods of time
6. When in storage, it is recommended to operate the valve manually once every three months to maintain best performance.
7. Do not store near electrical equipment, motors or other equipment which may generate Ozone.
8. If the valve(s) are to be stored for a long duration, follow the recommendations of IMO-S1.

## 3. INSTALLATION

### 3.1 GENERAL

Remove packaging and check that the valve is clean inside.

Clean valve if necessary. Do not use diesel, thinner, or kerosene to clean the valve

#### CAUTION:

WHEN HANDLING THE VALVE OR THE VALVE PACKAGE, BEAR IN MIND ITS WEIGHT!

Follow the lifting methods shown in the **Figure 1**.




Figure 1 Lifting of the valve assembly

Flush the pipeline carefully before installing the valve. Foreign objects, such as dirt, sand, weld slag, or pieces of welding electrodes, will damage the disc and seal.

When installing the valve immediately after a pipe elbow, the valve shaft must be directed toward the center point of the pipe as is shown in the figure below. This is especially important when the valve is used as a control valve.




Figure 2 Mounting after a pipe elbow

The valve shaft of the butterfly valve mounted after a centrifugal pump must be perpendicular to the pump shaft as shown in the figure below.




Figure 3 Mounting after a centrifugal pump

### 3.2 INSTALLING IN THE PIPELINE

#### WARNING:

BEFORE YOU INSTALL A BUTTERFLY VALVE IN, OR REMOVE IT FROM THE PIPELINE, CYCLE THE VALVE CLOSED. THE VALVE MUST BE INSTALLED IN THE CLOSED POSITION. FAILURE TO FOLLOW THESE INSTRUCTIONS CAN CAUSE MECHANICAL DAMAGE TO THE VALVE AND MAY RESULT IN PERSONAL INJURY.

#### WARNING:

THE VALVE SHOULD BE TIGHTENED BETWEEN FLANGES USING FASTENERS COMPATIBLE WITH THE APPLICATION, AND IN COMPLIANCE WITH APPLICABLE PIPING CODES AND STANDARDS. CENTER THE VALVE CAREFULLY BETWEEN FLANGES. DO NOT ATTEMPT TO CORRECT PIPELINE MISALIGNMENT BY MEANS OF FLANGE BOLTING!

#### WARNING:

GOOD PRACTICE DICTATES THAT ONCE INSTALLED, BUT PRIOR TO FIRST USE, THE VALVE IS LEAK TESTED IN PLACE TO ASSURE LEAK-TIGHTNESS HAS NOT BEEN COMPROMISED BY THE INSTALLATION PROCESS. PRESSURIZE THE PIPELINE AND CHECK FOR THROUGH LEAKAGE BETWEEN THE SEAL AND DISC AND EXTERNAL LEAKAGE AT THE FLANGE FACES.

#### CAUTION:

DO NOT USE FLANGE GASKETS. THE RUBBER SEAL EXTENDS FROM BOTH SIDES OF THE VALVE TO SEAL DIRECTLY AGAINST THE FLANGE FACES.

The valve may be installed in any position and offers tight shut-off in either flow direction.

1. Read all **WARNINGS!**
2. **IMPORTANT:** Actuator or handle stop must be used to stop the disc position. The valve itself does not have internal or external stops to limit disc rotation.
3. Before installing a valve in the pipeline, be sure that the actuator is attached so that clockwise rotation, viewed from above, closes the valve. Fully close the valve before installing in the pipeline.

**CAUTION:**

THE BUTTERFLY VALVE MUST BE CENTERED BETWEEN FLANGES TO AVOID DISC-PIPE CONTACT WHICH COULD DAMAGE THE DISC AND SHAFT. ANY FLANGE OR PIPELINE WELDING SHOULD BE DONE PRIOR TO INSTALLATION OF VALVES. IF THIS IS IMPOSSIBLE, PROTECTIVE COVERING OR SHIELDS MUST BE PLACED IN THE PIPELINE BETWEEN THE VALVE AND THE AREA BEING WELDED PRIOR TO WELDING. NOT ONLY MUST THE VALVE BE PROTECTED AGAINST WELD SLAG, BUT ALSO AGAINST ANY EXCESSIVE HEAT, WHICH COULD CAUSE SEAL DAMAGE. IT IS ESSENTIAL THAT ALL WELD SLAG, RODS, DEBRIS, TOOLS, ETC., BE REMOVED FROM THE PIPELINE BEFORE VALVES ARE INSTALLED OR CYCLED.

4. Secure the valve between flanges. Compress the flange seal **EVENLY** by tightening the fasteners in gradual steps in an alternating sequence as recommended per ASME PCC-1, Guidelines for Pressure Boundary Bolted Flange Joint Assembly. Recommended flange bolt tightening torques are given in **Section 3.4**.
5. After installation and pressure testing for leakage, operate the valve gradually from full close to full open to verify proper operation.

### 3.3 FLANGE BOLT SIZE AND LENGTH TABLES

**NOTE:** All fastener lengths are in millimeter and include a standard flat washer under each nut or rotating face as shown in the pictures.




Figure 4

### 3.4 WAFER BODY & LUG BODY




Figure 5

Size		PN10							
DN	NPS	Bolt size	No. of A, B Bolts	A	B	Or, No. of C, D Bolts	C	D	T
50	2	M16	4	130	110	8	65	45	20
65	2 1/2	M16	4	130	110	8	65	45	20
80	3	M16	8	135	110	16	65	45	20
100	4	M16	8	145	120	16	65	50	22
125	5	M16	8	145	125	16	65	50	22
150	6	M20	8	160	135	16	75	55	24
200	8	M20	8	160	140	16	80	55	24
250	10	M20	12	175	150	24	80	60	26
300	12	M20	12	185	160	24	85	65	26
350	14	M20	16	195	170	32	90	65	30
400	16	M24	16	230	200	32	100	70	32
450	18	M24	20	250	220	40	110	75	36
500	20	M24	20	265	235	40	120	75	38
600	24	M27	20	310	280	40	130	85	42

Size		ASME B16.5 Class 150							
DN	NPS	Bolt size	No. of A, B Bolts	A	B	Or, No. of C, D Bolts	C	D	T
50	2	5/8-11UNC	4	135	110	8	70	50	20
65	2 1/2	5/8-11UNC	4	135	120	8	70	50	22
80	3	5/8-11UNC	4	140	130	8	70	50	24
100	4	5/8-11UNC	8	145	130	16	75	55	24
125	5	3/4-10UNC	8	160	140	16	80	55	24
150	6	3/4-10UNC	8	160	140	16	80	55	25
200	8	3/4-10UNC	8	170	150	16	85	60	28
250	10	7/8-9UNC	12	185	160	24	90	65	30
300	12	7/8-9UNC	12	200	180	24	90	70	32
350	14	1-8UNC	12	215	190	24	100	75	35
400	16	1-8UNC	16	240	220	32	110	80	37
450	18	1 1/8-8UNC	16	265	240	32	120	90	40
500	20	1 1/8-8UNC	20	285	260	40	120	90	43
600	24	1 1/4-8UN	20	330	300	40	130	100	48

Size		PN16							
DN	NPS	Bolt size	No. of A, B Bolts	A	B	Or, No. of C, D Bolts	C	D	T
50	2	M16	4	130	120	8	65	45	20
65	2 1/2	M16	4	130	120	8	65	45	20
80	3	M16	8	130	120	16	65	45	20
100	4	M16	8	140	130	16	70	50	22
125	5	M16	8	145	135	16	75	50	22
150	6	M20	8	160	140	16	75	55	24
200	8	M20	12	170	145	24	80	55	26
250	10	M24	12	190	165	24	90	60	29
300	12	M24	12	210	180	24	90	70	32
350	14	M24	16	210	185	32	95	70	35
400	16	M27	16	250	215	32	110	80	38
450	18	M27	20	270	240	40	110	90	42
500	20	M30	20	300	270	40	125	100	46
600	24	M33	20	350	320	40	145	110	55



Size		AS 2129 TABLE D							
DN	NPS	Bolt size	NO. OF A, B BOLTS	A	B	Or, No. of C, D Bolts	C	D	T
50	2"	M16	4	125	100	8	60	40	17
65	2½"	M16	4	130	105	8	65	40	17
80	3"	M16	4	130	110	8	65	40	19
100	4"	M16	4	135	115	8	65	45	19
125	5"	M16	8	145	125	16	65	45	21
150	6"	M16	8	145	125	16	65	45	21
200	8"	M16	8	150	130	16	65	50	22
250	10"	M20	8	175	150	16	80	55	25
300	12"	M20	12	185	160	24	80	55	25
350	14"	M24	12	205	170	24	90	65	29
400	16"	M24	12	230	195	24	90	65	29
450	18"	M24	12	250	215	24	95	70	32
500	20"	M24	16	260	225	32	95	70	32
600	24"	M27	16	300	260	32	120	85	35

Size		AS 2129 TABLE E							
DN	NPS	Bolt size	NO. OF A, B BOLTS	A	B	Or, No. of C, D Bolts	C	D	T
50	2"	M16	4	130	105	8	65	45	19
65	2½"	M16	4	130	110	8	65	45	19
80	3"	M16	4	130	110	8	65	45	19
100	4"	M16	8	145	120	16	65	45	22
125	5"	M16	8	150	125	16	65	45	22
150	6"	M20	8	160	130	16	75	50	22
200	8"	M20	8	165	140	16	80	55	25
250	10"	M20	12	175	150	24	80	55	25
300	12"	M24	12	205	170	24	90	65	29
350	14"	M24	12	210	175	24	95	70	32
400	16"	M24	12	235	200	24	95	70	32
450	18"	M24	16	250	220	32	100	70	35
500	20"	M24	16	270	240	32	100	75	38
600	24"	M30	16	315	280	32	130	100	41

## 3.5 FLANGE BOLT TIGHTENING TORQUE

**NOTE:** Torque values are for clean bolts with well lubricated threads and lubrication between nut and washer face.

Valve Size		Torque	
DN	NPS	ft-lb	N.m
50	2	30	40
65	2 1/2	30	40
80	3	35	50
100	4	40	55
125	5	45	60
150	6	50	65
200	8	55	75
250	10	75	100
300	12	110	150
350	14	120	160
400	16	120	160
450	18	125	170
500	20	125	170
600	24	150	200

## 3.6 OPERATION AND ACTUATOR

### WARNING:

WHEN INSTALLING THE ACTUATOR ON THE VALVE, MAKE SURE THAT THE VALVE ASSEMBLY FUNCTIONS PROPERLY. INFORMATION ON ACTUATOR INSTALLATION IS GIVEN IN **SECTION 5** OR IN THE SEPARATE ACTUATOR INSTRUCTIONS.

### WARNING:

BEFORE INSTALLING THE VALVE AND ACTUATOR, BE SURE THAT THE INDICATOR POINTER ON TOP OF THE ACTUATOR IS CORRECTLY INDICATING THE VALVE POSITION. FAILURE TO ASSEMBLE THESE PRODUCTS TO INDICATE CORRECT VALVE POSITION COULD RESULT IN DAMAGE OR PERSONAL INJURY.

### WARNING:

FAILURE TO PROPERLY MOUNT THE HANDLE MAY RESULT IN IMPROPER VALVE OPERATION, MAY RESULT IN DAMAGE OR PERSONAL INJURY.

### WARNING:

HIGH LINE PRESSURE MAY CREATE ENOUGH FORCES TO PULL THE MANUAL LEVER HANDLE OUT OF THE OPERATOR'S HAND.

1. The valve package should be installed in the pipeline in a manner that allows plenty of room for actuator removal.
2. The actuator must not touch the pipeline, because pipeline vibration may interfere with its operation.
3. Actuator mounting instructions are in **Section 5**.

## 3.7 COMMISSIONING

Ensure that there is no dirt or foreign objects left inside the valve or pipeline. Flush the pipeline carefully. Make sure that the valve is fully open when flushing.

Ensure that all nuts, fittings, and cables are properly fastened. If so equipped, check that the actuator positioner and/ or switch(s) are correctly adjusted. Actuator adjustment is explained in **Section 6**. To adjust any accompanying device(s) refer to the separate control equipment instruction manuals.

## 4. MAINTENANCE

### WARNING:

BEFORE YOU REMOVE IT FROM THE PIPELINE, CYCLE THE VALVE CLOSED. THE VALVE MUST BE REMOVED IN THE CLOSED POSITION. FAILURE TO FOLLOW THESE INSTRUCTIONS WILL CAUSE MECHANICAL DAMAGE TO THE VALVE AND MAY RESULT IN PERSONAL INJURY.

## 4.1 GENERAL

Although Neles Easyflow valves are designed to work under severe conditions, proper preventative maintenance can significantly help to prevent unplanned downtime and reduce the total cost of ownership. Valmet recommends inspecting valves at least every five (5) years. The inspection and maintenance frequency depend on the actual application and process condition.

Overhaul maintenance consists of replacing the seal and bushings. These parts may be obtained from Valmet or an Authorized Valmet Distributor.

### WARNING:

FOR YOUR SAFETY, IT IS IMPORTANT THE FOLLOWING PRECAUTIONS BE TAKEN PRIOR TO REMOVAL OF THE VALVE FROM THE PIPELINE OR BEFORE ANY DISASSEMBLY:

1. Be sure you know what fluid is in the pipeline. If there is any doubt, double-check with the proper supervisor.
2. Wear any Personal Protective Equipment (protective clothing or equipment) required when working with the fluid involved.
3. Depressurize the pipeline and drain the pipeline fluid. Differential pressure across and flow around a butterfly valve disc can cause the valve to open.
4. **NOTE:** Do not pressurize the valve without a handle or an actuator mounted on it! Do not remove a handle or an actuator from a valve under pressure! Damage or personal injury may result!
5. These valves are suitable for a wide variety of fluids and gases. Be certain that the valve materials replaced are suitable for the application.

## 4.2 ACTUATED VALVE

It is generally most convenient to detach the actuator and its auxiliary devices before removing the valve from the pipeline. If the valve package is small or if it is difficult to access, it may be more practical to remove the entire assembly.

**NOTE:** To ensure proper reassembly, observe the position of the actuator and positioner/limit switch with respect to the valve before detaching the actuator.

**WARNING:**

ALWAYS DISCONNECT THE ACTUATOR FROM ITS POWER SOURCE, PNEUMATIC, HYDRAULIC OR ELECTRICAL, BEFORE ATTEMPTING TO REMOVE IT FROM THE VALVE!

**WARNING:****BEWARE OF DISC MOVEMENT!**

KEEP HANDS, OTHER PARTS OF THE BODY, TOOLS AND OTHER OBJECTS OUT OF THE OPEN FLOW PORT. LEAVE NO FOREIGN OBJECTS INSIDE THE VALVE OR PIPELINE. WHEN THE VALVE IS ACTUATED, THE DISC FUNCTIONS AS A CUTTING DEVICE.

**WARNING:**

DO NOT REMOVE A SPRING-RETURN ACTUATOR UNLESS A STOP-SCREW IS CARRYING THE SPRING FORCE!

1. Detach the air supply, electrical supply, hydraulic supply and control signal cables or pipes from their connectors.
2. Unscrew the actuator mounting screws safely with an appropriate tool.
3. Lift the actuator straight up in line with the valve stem until the connection between actuator drive and valve stem is completely disengaged.
4. Place actuator in a safe location to avoid damage or personal injury.

## 4.3 VALVE REMOVAL

1. Read all **WARNINGS!**
2. Valve must be fully closed before removing it from the pipeline.

**CAUTION:**

Valves equipped with spring-to-open (air-to-close) actuators must be disconnected from the actuators and then closed. Valves must be closed while removing them from the pipeline.

## 4.4 VALVE DISASSEMBLY

**NOTE:** It is good practice to replace the seal and bearings any time a valve is disassembled.

1. Read all **WARNINGS!**
2. Place the valve on a bench or other suitable working space.

**WARNING:**

REMOVING THE SHAFT WILL FREE THE DISC; THEREFORE, THE DISC MUST BE SUPPORTED TO PREVENT FALLING WHICH COULD RESULT IN DAMAGE OR PERSONAL INJURY!

3. Operate the valve so the disc is in the closed position
4. Remove the anti-blowout bolt (9) from the valve body (1).
5. Remove the spring dowel pin (6) and the bottom stem (4).
6. Remove the top stem (3) carefully & also remove the V-Ring(13).
7. Remove the seal (5) and disc (2) from the valve body (1).

**CAUTION:**

PROTECT THE DISC EDGE AT ALL TIMES TO AVOID DAMAGE.

## 4.5 CHECKING PARTS

1. Clean all disassembled parts.
2. Check the stems (3, 4) and disc (2) for damage. Pay particular attention to the sealing areas.
3. Replace any damaged parts.
4. Replace any parts that have cracks, gouges or pits that will affect sealing.

**NOTE:** When ordering spare parts, always include the following information:

- a. Valve type code as per technical bulletin and model number from name plate,
- b. If the valve is serialized – the serial number (stamped on the valve body or name plate) or applicable manufacturing order number,
- c. Spare part set number as per **Table 2**.

## 4.6 VALVE ASSEMBLY

Numbers in ( ) refer to items shown in the exploded view

**NOTE:** Silicone grease may not be compatible with or permitted in the process application. Other non-petroleum based lubricants may be used that are compatible with the valve materials of construction and the process application.

1. Clean all valve components, if not previously done.

**CAUTION:**

THE USE OF A WIRE BRUSH, ABRASIVE PAPER/CLOTH, OR ANY SHARP OBJECT CAN DAMAGE THE SEAL.

2. Inspect all components for damage before assembling the valve. Look for damage to the sealing areas on the disc, stems, and body, and for wear in the bearing areas.
3. Carefully clean and polish the disc sealing surface. It should be free from all grooves and scratches.
4. If the disc is slightly damaged, it may be possible to smooth the sealing surface with fine emery cloth, a fine stone, or the equivalent. If deep scratches are present, replace the disc or return the valve to the factory for service.
5. Apply a light coating of Silicon grease to the seal inside diameter and the top and bottom stem holes.
6. Apply a light coating of Silicone grease to the disc edge.
7. Insert the bottom stem bushing (7) into the lower disc bore.
8. Insert the disc (2) into the seal (5).
9. Apply a thin coating of Silicon grease to the inside surface of the body (1) including the top and bottom stem holes.
10. Insert the seal (5) and disc (2) assembly into the valve body (1).
11. Apply Silicone grease to the bottom stem (4) and insert into the body bore and align the hole for the spring dowel (6). Drive the spring dowel (6) into position so it is equally engaged on both sides.

12. Install bushings (7), spring rings (8) & V-Ring (13) on the top stem (3). Apply Silicone grease and insert top stem assembly into the upper body bore. Ensure the line marked on top of the stem in aligned with the disc edge when engaging the stem and disc.
13. Install the anti-blowout bolt (9) in the valve body.
14. If the actuator was removed reinstall and set the actuator stops as described in the **ACTUATOR MOUNTING INSTRUCTIONS** Section.

## 4.7 TESTING THE VALVE

### **WARNING:**

WHEN PRESSURE TESTING, EXERCISE CAUTION AND MAKE SURE ALL EQUIPMENT USED IS IN GOOD WORKING CONDITION AND APPROPRIATE FOR THE INTENDED PRESSURE.

### **WARNING:**

GOOD PRACTICE DICTATES THAT ONCE INSTALLED, BUT PRIOR TO FIRST USE, THE VALVE IS LEAK TESTED IN PLACE TO ASSURE LEAK-TIGHTNESS HAS NOT BEEN COMPROMISED BY THE INSTALLATION PROCESS. INSTALLATION ACTIONS THAT CAN CAUSE LEAKAGE INCLUDE, BUT ARE NOT LIMITED TO; WRENCHING, SOLDERING, WELDING AND/OR HOISTING.

### **WARNING:**

WHEN PERFORMING ANY TESTS, NEVER EXCEED THE MAXIMUM OPERATING PRESSURE OR MAXIMUM SHUT-OFF PRESSURE LISTED ON THE LABEL PLATE!

Should it become necessary to perform a leak test of the valve prior to its installation in the pipeline, follow the procedure outlined below.

1. Before pressurizing the valve be sure all actuator mounting fasteners are tight, and that the power or pressure is applied to the actuator to maintain the valve in the closed position.
2. The valve should be installed between flanges or in a testing apparatus. If flanges are used, refer to **INSTALLATION** Section. If a testing device other than flanges is used, the clamping force of the device must be comparable with flange bolt loads on the valve.
3. Partially open the valve. Verify that you do not have a seal between the seal and the disc. Exercise caution when cycling a valve in the test apparatus to avoid possible disc damage from the disc striking the test fixture.
4. Cap the downstream vent and apply the rated differential pressure to the valve. Check the shaft seals, and flange faces for leakage. This can be done by applying a liquid mixture of soap and water at all seal joints and watching for bubbles.

**IMPORTANT:** If leakage is detected between the valve and flanges **STOP IMMEDIATELY**. Mark the area of leakage. Vent the valve, and when it has returned to 0 psi (0 bar), retighten the flange bolts in the area. Pressurize the valve checking the flange again. If leakage persists, disassemble and inspect flange face and seal for damage.

5. If leakage is detected at the stem seals, vent the pressure, remove the valve, disassemble, and inspect for damage.
6. If the valve passes the external leak test, proceed with the following steps for internal seal leak test.
7. Vent the valve, and when it has returned to 0 psi (0 bar), cycle the valve closed.

8. Attach a small tube or hose to the downstream flange.
9. Be sure power/pressure is still applied to the actuator. Pressurize the upstream flange to the rated shut-off pressure. Check for leakage passing out through the free end of the tube/hose.
10. If leakage is detected, vent the pressure, cycle the valve open and close, and retest.
11. Pressurize the valve and check the leakage. If leakage cannot be stopped, adjust the closed position stop so that leakage is minimized, or disassemble and repair valve.

**NOTE:** Initial downstream movement of the disc can be mistaken for leakage. Wait at least 5 minutes after applying pressure before checking for leakage.

12. If the actuator has been removed, reinstall and set the actuator stops as described in the **ACTUATOR MOUNTING INSTRUCTION** Section. Do not install and tighten flanges on a newly reseated valve until the actuator stops are properly set and the valve is fully closed. Incorrect disc positioning may cause damage to a new seal when the valve is compressed between flanges for the first time. **NOTE:** After installation of a new seal, torque can be higher for a few cycles.

## 5. ACTUATOR

### **WARNING:**

BEFORE INSTALLING THE VALVE AND ACTUATOR, BE SURE THAT THE INDICATOR POINTER ON TOP OF THE ACTUATOR IS CORRECTLY INDICATING THE VALVE POSITION. FAILURE TO ASSEMBLE THESE PRODUCTS TO INDICATE CORRECT VALVE POSITION COULD RESULT IN DAMAGE OR PERSONAL INJURY.

### **CAUTION:**

WHEN INSTALLING OR SERVICING A VALVE/ACTUATOR ASSEMBLY, THE BEST PRACTICE IS TO REMOVE THE ENTIRE ASSEMBLY FROM SERVICE.

### **CAUTION:**

AN ACTUATOR SHOULD BE REMOUNTED ON THE VALVE FROM WHICH IT WAS REMOVED. THE ACTUATOR MUST BE CHECKED AND READJUSTED FOR PROPER OPEN AND CLOSE POSITION EACH TIME IT IS REMOUNTED.

### **WARNING:**

THE VALVE BODY AND MOUNTING INTERFACE HAS BEEN DESIGNED TO SUPPORT THE WEIGHT AND OPERATION OF Neles ACTUATORS AND RECOMMENDED ACCESSORIES. USE OF THIS INTERFACE TO SUPPORT ADDITIONAL EQUIPMENT SUCH AS PEOPLE, LADDERS, ETC. MAY RESULT IN THE FAILURE OF THE VALVE OR ACTUATOR AND MAY CAUSE PERSONAL INJURY.

### **WARNING:**

WHEN MOUNTING THE ACTUATOR MAKE SURE THAT THE VALVE AND ACTUATOR ARE BOTH IN THE SAME POSITION. MOUNTING AN OPEN ACTUATOR TO A CLOSED VALVE COULD RESULT IN DAMAGE OR PERSONAL INJURY.

**WARNING:****BEWARE OF DISC MOVEMENT!**

KEEP HANDS, OTHER PARTS OF THE BODY, TOOLS AND OTHER OBJECTS OUT OF THE OPEN FLOW PORT. LEAVE NO FOREIGN OBJECTS INSIDE THE VALVE OR PIPELINE. WHEN THE VALVE IS ACTUATED, THE DISC FUNCTIONS AS A CUTTING DEVICE.

## 5.1 ACTUATOR MOUNTING INSTRUCTIONS

1. When a spring-return actuator is being mounted, the valve should be in the closed position for spring-to-close operation or in the open position for the spring-to-open operation. When an electric or double-acting pneumatic actuator is being mounted, the valve position should correspond to the indicated actuator position.
2. Assemble actuator onto the valve, ensuring full engagement between the stem and actuator drive, and the actuator fully contacts the mounting face on the valve.
3. Use appropriate tool to tighten actuator mounting screws safely to the torque listed in **Table 1**.

**CAUTION:**

THE USE OF A WIRE BRUSH, ABRASIVE PAPER/CLOTH, OR ANY SHARP OBJECT CAN DAMAGE THE SEAL.

**CAUTION:**

DO NOT EXCEED THE TIGHTENING TORQUE. APPLYING EXCESSIVE TIGHTENING TORQUE CAN DAMAGE THE ALUMINUM THREADS IN THE ACTUATOR BODY.

Table 1	
Torque to Aluminum Body Actuators	
Bolt Size	No Lubrication to Screws
mm	N.m
M6	6.8
M8	14.9
M10	30
M12	52
M16	122
M20	230

4. Cycle actuator and verify proper disc position in both open and closed positions. Adjust the actuator travel stops as necessary following instructions described in the actuator manual to these proper valves open and closed positions:

**Valve Open:**

Disc face perpendicular with the flange face.

**Valve Closed:**

Disc face parallel to flange face within 0.5 mm (0.020 inch).

## 6. SERVICE / SPARE PART

We recommend that valves be directed to Valmet service centers for maintenance. The service centers are equipped to provide rapid turn-around at a reasonable cost and offer warranty for reconditioning based on condition of each valve.

**NOTE:** When sending goods to the service center for repair, do not disassemble them. Clean the valve carefully and flush the valve internals. Include the material safety datasheet(s) (MSDS) for all media flowing through the valve. Valves sent to the service center without MSDS datasheet(s) will not be accepted.

For further information on spare parts and service or assistance visit our web-site at [www.valmet.com/flowcontrol/](http://www.valmet.com/flowcontrol/)

**NOTE:** When ordering spare parts, always include the following information:

- a. Valve type code as per technical bulletin and model number from name plate,
- b. If the valve is serialized – the serial number (stamped on the valve body or name plate) or applicable manufacturing order number
- c. Spare part set number as per **Table 2**.

## 7. WELDING WARNING

**WARNING:**

WELDING AND/OR GRINDING OF STAINLESS STEEL AND OTHER ALLOY STEELS CONTAINING CHROMIUM METAL MAY CAUSE THE RELEASE HEXAVALENT CHROMIUM. HEXAVALENT CHROMIUM, CHROMIUM(VI) OR CR(VI), IS KNOWN TO CAUSE CANCER. BE SURE TO USE ALL APPROPRIATE PPE WHEN WELDING METALS CONTAINING CHROMIUM. IF YOU HAVE ANY QUESTIONS CONSULT YOUR SUPERVISOR.

Table 2					
*Sign. 1	Sign. 2	Sign. 3	Body type	Notes	Sign. 4
Valve size	Series	W	Applicable only for wafer body	a)	Seat material
50	JA	L	Applicable only for lug body	a)	EP = Ethylene-Propylene (EPDM) NB = Nitrile (Buna-N, NBR) VT = Fluoroelastomer (FKM)
65		<u>Notes:</u> a) Spare parts are common for Wafer & Lug end valves for sizes - DN50, DN65, DN150, DN200, DN250, DN350 & DN600.			
80					
100					
125					
150					
200					
250					
300					
350					
400					
450					
500					
600					
* leave space after Sign.1 Spare parts are common between PN3.5, PN6, PN10, PN16 and ASME Class 150 rated valves					

# 9. EXPLODED VIEW

DN 50 - DN 600




Figure 6



# 10. EU DECLARATION OF CONFORMITY FOR ATEX APPROVED VALVES



## EU DECLARATION OF CONFORMITY for ATEX approved valves



Manufacturer:  
Valmet Flow Control Private Limited  
E-61, Additional MIDC Area, Anand Nagar,  
421506 Ambernath (East)  
Maharashtra, India

EU Authorised Representative: Valmet Flow Control Oy, Vanha Porvoontie 229, 01380  
Vantaa, Finland. Contact details: [+358 10 417 5000](tel:+358104175000)

This declaration of conformity is issued under the sole responsibility of the manufacturer.

Product:	Neles Easyflow Butterfly valves
Type:	JA-series
ATEX group and category:	Ex II 2 GD, II 3 GD
Ex GAS:	Ex h IIC 85°C...Tmax Gb/Gc
Ex DUST:	Ex h IIIC T85°C...T(Tmax) Db/Dc

Tmax= valve max. temperature in name plate

### Manufacturer's certificates:

Standard / Directive	Notified Body and NoBo number	Certificate No.
ISO 9001:2015	LRQA (Certification Body)	10531829
PED 2014/68/EU Module H	DNV Business Assurance Italy S.r.l. 0496	142306-2013-CE-FIN-ACCREDIA
ATEX 2014/34/EU Annex IV	DNV Product Assurance AS Norway 2460	Presafe 18 ATEX 91983Q Issue 6

ATEX 2014/34/EU Annex VIII technical files are archived by Notified Body number 0537

The object of the declaration described above is in conformity with the relevant Union harmonisation legislation:

PED 2014/68/EU	Valve
ATEX 2014/34/EU	Non-electrical equipment

### Main components:

Valve: The valve is suitable for service up to PED Cat III Valve design standard: ASME B16.34
---

Installation, Maintenance and Operating instructions manual (IMO) must be followed before installation in order to ensure proper and safe mounting and usage of equipment.

The product above is manufactured in compliance with the applicable European directives and technical specifications/standards EN10204. The product is in conformity with the customer order.

Instrumentation and accessories having equal protection concept, level and performance specification with the original can be presumed to be in conformity with this Declaration of Conformity.

Protection from e.g. static electricity caused by the process or connected equipment must be considered by the user (EN 60079-14 § 6). EN 60079-19 applies for modifications.

Non-electrical equipment is according EN 80079-37:2016 and EN 80079-36:2016. The actual surface temperature of non-electrical equipment is depended on the process and ambient conditions (EN 80079-36:2016 § 6.2.5 and 6.2.7). The protection from high or low temperature must be considered by the end user before put into service.

The product does not possess any residual risk according to hazard analysis conducted under the applicable directives providing that the procedures stated by the IMO are followed and the product is used under conditions mentioned in the technical specifications.

Documents with digital and/or e-signature conveyed by Valmet Flow Control conform to the Regulation (EU) No 910/2014 as well as the national code on e-signatures. In order to secure the integrity of the document, the authenticity of the sender, and indisputableness of the dispatch the identification is covered by individual ID codes, passwords, and by regularly changing passwords. The authorization to sign documents is based on organizational position and/or is task related. The impartial third party in the company bestows the access right with predefined authorities to particular databases.

Ambernath 10.9.2024

Juha Virolainen, Global Quality Director



# 11. TYPE CODE

## NELES EASYFLOW JA SERIES BUTTERFLY VALVE

### HOW TO ORDER

1.		2.	3.	4.	5.	6.	7.	8.	9.
200		JA	15	W	21	36	41	EP	A

1. sign	Size, DN (NPS ref.)
50	50 (2)
65	65 (2 1/2)
80	80 (3)
100	100 (4)
125	125 (5)
150	150 (6)
200	200 (8)
250	250 (10)
300	300 (12)
350	350 (14)
400	400 (16)
450	450 (18)
500	500 (20)
600	600 (24)

2. sign	Series
JA	

3. sign	Flange / rating
10	PN 10
16	PN 16
15	ASME Class 150
TD	AS 2129 Table D
TE	AS 2129 Table E

AS TABLES 2129 D and E. see page 8.

4. sign	Body type
W	Wafer type
L	Lug type

5. sign	Body material
21	GGG40 ductile iron
24	*GG25 cast iron
22	WCB carbon steel
36	CF8M stainless steel

\* GG25 body option not available for Class 150

6. sign	Disc material
21	GGG40 ductile iron (epoxy coated)
36	CF8M stainless steel

7. sign	Stem material
36	316 stainless steel
43	17-4PH H1150D Stainless steel
41	410 martensitic steel

8. sign	Seal
EP	Ethylene-Propylene (EPDM)
NB	Nitrile (Buna-N, NBR)

9. sign	Model Code
A	Mod A, modular butterfly valve platform

10. sign	Non-standard options
P3	Low torque reduced diameter disc (undercut disc) with PN3.5 shut-off rating
P6	Low torque reduced diameter disc (undercut disc) with PN6 shut-off rating

**NOTE:** As the use of the valve is application specific, a number of factors should be taken into account when selecting a valve for a given application. Therefore, some of the applications in which the valves are outside the scope of this document. If you have any questions concerning the use, application or compatibility of the valve with the intended service, contact nearest Valmet sales office for more information.

# 12. GENERAL SAFETY WARNINGS AND DISCLAIMERS

## General safety warnings

### Lifting

1. Always use a lifting plan created by a qualified person to lift this equipment. Lifting guidance is provided in this IMO (Installation, Maintenance and Operation manual) to assist in lifting plan development. Think about the center of gravity (CG) of the equipment being lifted. Make sure the CG is always under the central lifting point.
2. Valves may be equipped with lifting threads on the body or on the flanges. These are intended to be used with the lifting plan.
3. Use only correct and approved lifting devices. Ensure that lifting devices and straps are securely attached to the equipment prior to lifting.
4. Check, that lifting devices are not damaged and in good condition with a valid check stamp prior to use.
5. Workers must be trained for lifting and handling valves.
6. Never lift an assembly by the instrumentation (solenoid, positioner, limit switch, etc.) or by the instrumentation piping. Straps and lifting devices should be fitted to prevent damage to instrumentation and instrumentation piping. Failure to follow the lifting guidance provided may result in damage and personal injury from falling objects.

### Work activities on the valve

1. Wear your personal safety equipment. Personal safety equipment includes but is not limited to protective shoes, protective clothing, safety glasses, helmet, hearing protection and working gloves.
2. Always follow the local safety instructions in addition to the Valmet instructions. If Valmet instructions conflict with local safety instructions, stop work and contact Valmet for more information.
3. Before beginning service on the equipment, make sure that the actuator is disconnected from any kind of power source (pneumatic, hydraulic, and/or electric), and no stored energy is applied on the actuator (compressed spring, compressed air volumes, etc.). Do not attempt to remove a spring return actuator unless the stop screw is carrying the spring force.
4. Make sure that there is a LOTOTO (Lock Out / Tag Out / Try Out) procedure in place for the system in which the valve is installed and strictly follow it.
5. Always make sure that the pipeline is depressurized and in ambient temperature condition before maintenance work is started.
6. Keep hands and other body parts out of the flow port when the valve is being serviced and the actuator is connected to the valve. There is a high risk of serious injury to hands and/or fingers due to malfunction if the valve suddenly starts to operate.
7. Beware of Trim (Disc, Ball or Plug) movement even when the valve is disassembled. Trim may move simply due to the weight of the part or change in position of the valve. Keep hands or other body parts away from locations where they may be injured by movement of the trim. Do not leave objects near or in the valve port which may fall in and need to be retrieved.

## General disclaimers

### Receiving, handling and unpacking.

1. Respect the safety warnings above!
2. Valves are critical components for pipelines to control high pressure fluids and must therefore be handled with care.

3. Store valves and equipment in a dry and protected area until the equipment is installed.
4. Do not exceed the maximum storage temperatures given in the IMO (installation, maintenance, and operating instructions).
5. Keep the original packaging on the valve as long as possible to avoid environmental contamination by dust, water, dirt, etc.
6. Remove the valve endcaps just before mounting into the pipeline.
7. FOR YOUR SAFETY IT IS IMPORTANT TO FOLLOW THESE PRECAUTIONS BEFORE REMOVAL OF THE VALVE FROM THE PIPELINE OR ANY DISASSEMBLY:
  - Be sure you know what flow medium is in the pipeline. If there is any doubt, confirm with the proper supervisor.
  - Wear any personal protective equipment (PPE) required for working with the flow medium involved in addition to any other PPE normally required.
  - Depressurize the pipeline, bring to ambient temperature, and drain the pipeline flow medium.
  - Cycle the valve to relieve any residual pressure in the body cavity.
  - After removal but before disassembly, cycle the valve again until no evidence of trapped pressure remains.
  - The valves with offset shaft (Butterfly, eccentric rotary plug) have greater trim area on one side of the shaft. This will cause the valve to open when pressurized from the preferred direction without a locking handle or an actuator installed.
  - **WARNING: DO NOT PRESSURIZE THE ECCENTRIC VALVE WITHOUT A HANDLE OR AN ACTUATOR MOUNTED ON IT!**
  - **WARNING: DO NOT REMOVE A HANDLE OR AN ACTUATOR FROM AN ECCENTRIC VALVE WHILE PRESSURIZED!**
  - Before installing the eccentric valve in or remove it from the pipeline, cycle the valve closed. Eccentric valves must be in the closed position to bring the trim within the face to face of the valve. Failure to follow these instructions will cause damage to the valve and may result in personal injury.

### Operating

8. The identification plate (ID-plate, type plate, nameplate, or engraved markings) on the valve gives the information of max. process conditions to the valve.
9. (For soft seats) The practical and safe use of this product is determined by both the temperature and pressure ratings of the seat and body. Read the identification plate and check both ratings. This product is available with a variety of seat materials. Some seat materials have pressure ratings that are lower than the body ratings. All body and seat ratings are dependent on the valve type, size and material of the body and seat. Never exceed the marked rating.
10. Temperatures and pressures must never exceed values marked on the valve. Exceeding these values may cause uncontrolled release of pressure and process medium. Damage or personal injury may result.
11. The operating torque of the valve may rise over time due to wear, particles or other damage of the seat. Never exceed the actuator torque preset values (air supply, position). Application of excessive torque may cause damage to the valve.
12. Valmet valves typically are designed to be used in atmospheric conditions. Do not use valves under external pressurized conditions unless specifically designed and explicitly marked for this service.

13. Avoid Pressure shocks or water hammer. Systems with high pressure valves should be equipped with a bypass to reduce the differential pressure before opening the valve to avoid pressure shock.
  14. Avoid thermal shock. High temperature, Low temperature and cryogenic valves should be operated in a way that limits the rate of increase or decrease in temperature. The valve should be thermally stabilized before being pressurized.
  15. Materials of the valve are carefully selected for the process conditions. Changes to the process media can have a major impact on function and safety of the valve. Always confirm the materials are suitable for the service prior to installation.
  16. As the use of the valve is application specific, several factors should be considered when selecting a valve for a given application. Therefore, some situations in which the valves are used are outside the scope of this manual.
  17. It is the end user's responsibility to confirm compatibility of the valve materials with the intended service, however if you have questions concerning the use, application, or compatibility of the valve for the intended service, contact Valmet for more information.
  18. Never use a valve with enriched or pure oxygen if the valve is not explicitly designed and cleaned for oxygen. Selected materials and design have a major impact on the safety to operate the valve with oxygen.
  19. Valves intended for use in or with explosive atmospheres must be equipped with a grounding device and marked according ATEX (or equivalent international standards).
  20. Manual handles are available for specific butterfly valve sizes and maximum line pressures. Do not operate a valve with a handle or wrench outside the size and pressure limits stated in the IMO. High line pressure may create a large enough force to pull the handle from the operator's hands. Damage or personal injury may result.
- Maintenance**
21. Respect the safety warnings above!
  22. Plan service and maintenance actions, that spare parts, lifting devices and service personnel is available.
  23. Maintain the valve within the recommended minimum maintenance intervals or within the recommended maximum operating cycles.
  24. Always make sure that the valve and the pipeline is depressurized before starting any kind of maintenance work at a valve.
  25. Always check the position of the valve before starting maintenance work. Follow the Lock out /tag out (LOTO) rules at the site before starting any maintenance activity.
    - See IMO for the correct stem position.
    - Consider that the positioner may give the wrong signals.
  26. Sealing materials (soft sealing parts) should be changed when the valve is in maintenance. Always use original equipment manufacturers (OEM) spare parts to ensure proper performance of the repaired valve.
  27. All pressure containing parts must be inspected visually for damage or corrosion. Damaged parts must be replaced.
  28. Valve pressure retaining parts and all internals must be inspected for corrosion or erosion which may result in reduced wall thickness on pressure retaining parts. Damaged pressure retaining parts must be replaced with original equipment manufacturer's (OEM) replacement parts or repaired to factory specifications by an authorized Valmet service partner in order to maintain the warranty.
  29. Do not use sharp tools, grinding machines, or files to work on functional surfaces such as sealing, seating or bearing surfaces as this can damage these surfaces.
  30. Check the condition of sealing surfaces on the seats, trim (disc, ball, plug, etc.), body and body cap. Replace parts if there are significant wear, scratches, or damage.
  31. Check the wear of bearings and bearing contact surfaces on the shaft and replace damaged parts if necessary.
  32. Do not weld on pressure retaining parts without an ASME and PED qualified procedure and personnel.
  33. Pressure retaining parts of valves in high temperature applications must be carefully examined for the effects of material creep and fatigue.
  34. Make sure that the valve is positioned in the correct flow direction into the pipeline.
  35. If the valves are marked to be suitable for explosive atmospheres, the correct function of the discharging device must be tested before returning to service.
  36. Always work in a clean environment. Avoid getting particles inside the valve due to machining, grinding, or welding nearby.
  37. Never store a valve in maintenance without flow port protection.
  38. When pressure testing valve seats, never exceed the maximum operating pressure of the system or the maximum shut- off pressure marked on the valve identification plate.
  39. Actuator mounting and unmounting:
    - Before installing the actuator on to the valve, be sure the actuator is properly indicating the valve position. Failure to assemble these to indicate correct valve position may result in damage or personal injury.
    - When installing or removing a linkage kit, best practice is to remove the entire linkage assembly, including couplings which may fall off the valve during lifting or when position changes.
    - Mounting sets have been designed to support the weight of the Valmet actuator and recommended accessories either as is or with additional actuator support. Use of the linkage to support additional equipment or additional weight such as people, ladders, etc. may result in equipment damage or personal injury.
  40. The valve should be installed between flanges using appropriate gaskets and fasteners that are compatible with the application, and in compliance with applicable piping codes and standards. Center the gaskets carefully when fitting the valve between the flanges. Do not attempt to correct pipeline misalignment by means of the flange bolting.
  41. Repairs on valves for special service like Oxygen, Chlorine, and Peroxide, have special requirements.
    - Parts must be cleaned appropriate to the service and protected from contamination prior to assembly.
    - Assembly areas and tools must be clean and dry to prevent contamination of the parts during assembly.
    - Test equipment must be clean and dry to prevent contamination during testing. This includes the test equipment internals that may allow particles or other contamination into the test medium during the test.
    - Lubrication shall be used only if specifically required in the instructions. Where lubrication is required, the lubricant must be approved for the service by the end user.

**Valmet Flow Control Oy**

Vanha Porvoontie 229, 01380 Vantaa, Finland.

[flowcontrol@valmet.com](mailto:flowcontrol@valmet.com)

Tel. +358 10 417 5000.

[www.valmet.com/flowcontrol](http://www.valmet.com/flowcontrol)

Subject to change without prior notice.

Neles, Neles Easyflow, Jamesbury, Stonel, Valvcon and Flowrox, and certain other trademarks, are either registered trademarks or trademarks of Valmet Oyj or its subsidiaries in the United States and/or in other countries.

