

Valvcon™ ADC-series

Continuous duty, universal on/off & modulating electric actuators with UL2, UL3, UL4, UL5, UL6 & UL7 options with "-UP" in the model number

Installation, maintenance and operating instructions




Table of contents

GENERAL	3	BOARD INSTALLATION / REPLACEMENT	15
Scope of the Manual	3	Safety Precautions	15
Actuator Markings	3	Safety Precautions Applicable to Units Equipped with a Back-Up Battery	15
Safety Precautions	3	Parts Verification	15
TRANSPORTATION AND STORAGE	3	BOARD REMOVAL	16
GENERAL INSTALLATION INFORMATION	3	Step by Step Instructions for the Removal of a Universal ADC/LADC-Series Actuator Control Board	16
Description of ADC-Series Universal		BOARD INSTALLATION	17
Control Actuators (with Optional Battery Back-Up)	3	Step by Step Instructions for the Installation of a Universal ADC/LADC-Series Actuator Control Board	17
Universal Control Board P/N VCB00010	4	REASSEMBLY	18
GENERAL INSTALLATION INFORMATION	5	DEFAULT SETTINGS AND MODES	19
Interface	5	TROUBLESHOOTING	19
Operation Mode Selector Pot	6	GENERAL OPERATING INFORMATION	20
Control Mode Selector Pot	6	Enclosure Ratings and Product	20
Travel Limit Cam and Switch Operation	6	Operating Temperature Limits	20
Built-In Heater/Thermostat Feature	7	Actuator Mounting	20
Torque Limit	7	Manual Override	20
MAIN ACTUATOR POWER	7	Lubrication	20
115VAC or 230VAC Power Wiring	7	Problem Prevention	20
24VAC Power Wiring	7	Warranty	20
12VDC or 24VDC Power Wiring	8	Repair Service/Spare Parts	20
ON/OFF CONTROL	8	SPECIFICATIONS & TECHNICAL INFORMATION	21
The three methods of On/Off Control:	8	Dimensions	22
On/Off Control Signal Wiring	8	ADC-series Universal Control Board	23
Set Up and Calibration	9	ADC-SERIES ACTUATORS BY MODEL NUMBER	24
POSITION CONTROL	10	ADDITIONAL ACTUATOR PRODUCTS AND ACCESSORIES FROM NELES	25
The three methods of Position Control	10		
Position Control Signal Wiring	10		
Set Up and Calibration	11		
Deadband Adjustment	12		
Signal Fail Options	12		
POSITION FEEDBACK AND STATUS INDICATORS	13		
Position Feedback	13		
Status Indicators	14		
POWER MANAGEMENT	14		
Battery	14		
Power Fail Controls	15		
"Wake Up"and Manually Drive Actuator	15		
Energy Save Mode	15		

READ THESE INSTRUCTIONS FIRST!

These instructions provide information about safe handling and operation of the valve.

If you require additional assistance, please contact the manufacturer or manufacturer's representative.

SAVE THESE INSTRUCTIONS!

Addresses and phone numbers are printed on the back cover.

All trademarks are property of their respective owners.

1. GENERAL

1.1 SCOPE OF THE MANUAL

This instruction manual contains important information regarding the installation, operation and maintenance of the Valvcon™ ADC-Series electric actuator. Please read these instructions carefully and save them for future reference.

1.2 ACTUATOR MARKINGS

WARNING

AS THE USE OF THE ACTUATOR IS APPLICATION SPECIFIC, A NUMBER OF FACTORS SHOULD BE TAKEN INTO ACCOUNT WHEN SELECTING AN ACTUATOR FOR A GIVEN APPLICATION. THEREFORE, SOME OF THE SITUATIONS IN WHICH THE ACTUATORS ARE USED ARE OUTSIDE THE SCOPE OF THIS MANUAL.

IF YOU HAVE ANY QUESTIONS CONCERNING THE USE, APPLICATION OR COMPATIBILITY OF THE ACTUATOR WITH THE INTENDED SERVICE, CONTACT NELES FOR MORE INFORMATION.

The actuator has an identification nameplate label attached to the base casting (see **Figure 1**).




Figure 1. Identification nameplate label

Identification nameplate label markings:

1. Model number
2. Serial number
3. Maximum output torque
4. Voltage
5. Current draw (full-load running)
6. Cycle time
7. Duty cycle
8. Applicable manual
9. Certifications marking

1.3 SAFETY PRECAUTIONS

WARNING

DO NOT EXCEED THE ACTUATOR PERFORMANCE LIMITATIONS!

EXCEEDING THE TORQUE LIMITATIONS MARKED ON THE ACTUATOR IDENTIFICATION NAMEPLATE LABEL MAY CAUSE DAMAGE TO THE ACTUATOR AND/OR FINAL DRIVE ELEMENT.

WARNING

DO NOT EXCEED THE ACTUATOR ELECTRICAL LIMITATIONS!

EXCEEDING THE ELECTRICAL LIMITATIONS MARKED ON THE ACTUATOR IDENTIFICATION NAMEPLATE LABEL MAY CAUSE DAMAGE TO THE ACTUATOR AND/OR PERSONAL INJURY.

WARNING

BEWARE OF MOVEMENT OF THE FINAL DRIVE ELEMENT AND ANY LINKAGE BETWEEN IT AND THE ACTUATOR!

KEEP HANDS, OTHER PARTS OF THE BODY, TOOLS AND OTHER OBJECTS OUT OF THE WAY OF MOVING PARTS. FAILURE TO DO THIS MAY RESULT IN DAMAGE OR PERSONAL INJURY!

2. TRANSPORTATION AND STORAGE

Check the actuator and any accompanying devices for any damage that may have occurred during transport.

Store the actuator carefully. Storage indoors in a dry place is recommended.

Move the actuator to its intended location just before installation.

The actuator is usually shipped in the full clockwise, (typically closed) position.

If the actuator(s) will be stored for a period longer than 90 days, follow the recommendations in IMO-S2 to maintain the actuator's integrity. Actuator is equipped with a battery; see section 9 of this manual.

3. GENERAL INSTALLATION INFORMATION

3.1 DESCRIPTION OF ADC-SERIES UNIVERSAL CONTROL ACTUATORS (WITH OPTIONAL BATTERY BACK-UP)

The ADC-Series consists of two different sized enclosures that cover different torque ranges. Model codes that start with "ADC" indicate the standard enclosure and a torque rating in the range from 150 to 600 in•lbs. "LADC" designates the larger enclosure and a torque rating in the range from 1000 to 3000 in•lbs.

The ADC-Series Actuators provide an optional internal battery pack to power the actuator in the event of a loss of external power. Actuators with battery back-up are identified in the model code by either a "UL2", "UL3", "UL4", "UL5", "UL6" or "UL7". The "UL2", "UL4" and "UL6" options are applicable in a standard ADC enclosure and the "UL3", "UL5" and "UL7" options are applicable in a LADC enclosure. The "UL4" and "UL5" options are factory-set for 180° operation with the MID position factory set at 90°; and the "UL6" and "UL7" options are factory-set for 270° operation.

The ADC-Series Actuators' base electronic package consists of two separate boards; P/N VCB00010 Universal Control Board and the Switching Power Supply allowing for the choice of 115VAC, 230VAC, 12VDC, 24VDC or 24VAC actuator power.

3.2 UNIVERSAL CONTROL BOARD P/N VCB00010

The Universal Control Board can be configured for either “Two-Wire” or “Three-Wire” On/Off control, or “4-20mA Analog”, “0-10VDC Analog”, or a “Resistive” Positioner Control. (See **Figure 5** in **Section 4.3**)

The Universal Control Board used in Positioner Control mode can be configured for Loss of Signal and has an adjustable input signal Dead Band.

The Universal Control Board allows independent 115VAC, 230VAC, 12VDC, 24VDC or 24VAC control signals from actuator power.

The Universal Control Board can provide analog position feedback, Power and Battery status and includes on-board battery status indicators.

The Universal Control Board with the optional Battery Back-up installed will allow you to select power “Fail” position as well as to choose “Park” or “Multi” cycling upon loss of actuator power.

The Universal Control Board has locked rotor stall protection.

The Universal Control Board has manual push button control and simple digital smart set functionality for entering and saving precise end of travel positions for calibration to the application.

The Universal Control Board has an easy to navigate color scheme for its input and output wiring terminal blocks, detailed below:

- Orange = Actuator Power
- Green = On/Off Control
- Yellow = Modulating Control
- White = Analog Feedback
- Light Blue = Status Feedback




Figure 2.

WARNING

DANGEROUS VOLTAGES ARE PRESENT INSIDE THE ACTUATOR COVER UNLESS THE POWER SUPPLY TO THE ACTUATOR HAS BEEN SHUT OFF OR DISCONNECTED. USE EXTREME CAUTION WHENEVER WORKING ON THE ACTUATOR WITH THE COVER REMOVED.

WARNING

ACTUATORS SHOULD BE PROPERLY GROUNDED AND WIRED IN ACCORDANCE WITH LOCAL ELECTRICAL CODE; SEE NAMEPLATE FOR MAXIMUM CURRENT DRAW.

WARNING

DO NOT MIS-APPLY HIGH-VOLTAGE SIGNALS TO LOW-VOLTAGE CIRCUITS. DO NOT POWER THE POSITION FEEDBACK CIRCUIT IF EXTERNAL POWER MODE IS NOT SELECTED.

SERIOUS DAMAGE TO THE CIRCUIT BOARD MAY RESULT.

WARNING

WHENEVER WORKING INSIDE THE ACTUATOR, CARE MUST BE TAKEN TO AVOID DAMAGE TO THE MACHINED FLANGE SURFACES ON THE COVER AND BASE CASTINGS. FAILURE TO DO SO CAN VOID THE ACTUATOR'S ENVIRONMENTAL CERTIFICATION.

WARNING

USE CARE WHENEVER WORKING WITH THE ACTUATOR COVER REMOVED. DAMAGE, SCRATCHES, OR DENTS ON THE MACHINED FLANGE SURFACES OF THE ENCLOSURE MAY VOID COMPLIANCE WITH NEMA, CSA, UL, AND/OR IEC SPECIFICATIONS. (SEE SECTIONS 6.3.5, 7.3.5, & 13)

WARNING

IF USING 24VAC TO POWER THE ACTUATOR, A DEDICATED POWER SUPPLY OR ISOLATION TRANSFORMER MUST BE USED.

WARNING

WHEN BATTERY IS CONNECTED TO BOARD, THE UNIT MAY DRIVE!

BEWARE OF MOVEMENT OF THE FINAL DRIVE ELEMENT AND ANY LINKAGE BETWEEN IT AND THE ACTUATOR!

KEEP HANDS, OTHER PARTS OF THE BODY, TOOLS AND OTHER OBJECTS OUT OF THE WAY OF MOVING PARTS. FAILURE TO DO THIS MAY RESULT IN DAMAGE OR PERSONAL INJURY!

WARNING

THIS UNIT CONTAINS A SEALED LEAD ACID BATTERY, REGULAR CHARGING IS NECESSARY WITH STORAGE LONGER THAN THREE MONTHS. TO CHARGE THE BATTERY, APPLY ONE OF THE INPUT VOLTAGES TO THE CORRESPONDING INPUT ON THE ACTUATOR, (NOT DIRECTLY TO THE BATTERY) AND LEAVE POWERED FOR AT LEAST TWENTY-FOUR HOURS.

HIGH AMBIENT TEMPERATURES CAN SHORTEN STORAGE LIFE. IT IS RECOMMENDED THAT THE BATTERY BE STORED AT 22°C +/- 5°C (72°F +/- 9°F). INSPECT THE BATTERY UPON RECEIPT, BEFORE INSTALLATION, AND AT REGULAR MAINTENANCE INTERVALS. REMOVE THE BATTERY FROM THE DEVICE FOR LONG-TERM STORAGE. FAILURE TO FOLLOW THIS CHARGING REQUIREMENT MAY RESULT IN REDUCED EFFECTIVE BATTERY LIFE.

4. GENERAL INSTALLATION INFORMATION

4.1 INTERFACE

1 - CAL – A continuous yellow LED indicates that the CAL (calibration) mode has been selected. A flashing yellow LED displays to the user how close they are to hitting the CAL point depending on the speed of the flashes. The CAL mode allows the user to calibrate the position tracking potentiometer without the use of an ohmmeter or other electronic instruments. In CAL mode the actuator will travel beyond the saved settings for the Zero and Span stop positions.

2 - ZERO – A continuous yellow LED indicates that the ZERO mode has been selected. ZERO mode permits the user to set the desired Zero end-of-travel stop position with a corresponding control signal value. The Zero position is typically the fully clockwise position and minimum control signal value, but Zero may be set at any position.

3 - MID - A continuous yellow LED indicates that the MID mode has been selected. MID mode permits the user to save the desired “MID” position. The MID position may be set at any position inside (between) the saved Zero and Span end-of-travel positions. (MID is not typically used with the Position Control configuration but can be used as a mid-travel “fail” position upon loss of external power, provided the actuator is equipped with a back-up battery.)

4 - SPAN – A continuous yellow LED indicates that the SPAN mode has been selected. SPAN mode permits the user to set the desired Span end-of-travel stop with a corresponding control signal value. Typically, the Span position is the fully counterclockwise position and maximum control signal value, but Span may be set at any position.

5 - MAN (MANUAL) – A continuous yellow LED indicates that Manual Control mode has been selected. The actuator will not respond to external control signals and the [CW] and [CCW] push buttons are enabled for manually driving the actuator in either direction. In Manual mode the actuator will not travel beyond the saved settings for the Zero and Span stop positions.

6 - RUN – A continuous green LED indicates that the normal operating mode has been selected. In RUN mode the actuator will respond external signals supplied to the Universal Control Board. This LED will turn off in Energy Save mode.

7 - ENTER – located directly below the mode selector and permits the user to activate modes and confirm settings by pressing the [ENTER] button.

8 - CW (CLOCKWISE) – A continuous yellow LED indicates that the actuator is driving in the CW direction. Located next to the Manual Control push button to drive the actuator in the CW direction.

9 - CCW (COUNTERCLOCKWISE) – A continuous yellow LED indicates the actuator is driving in the CCW direction. Located next to the Manual Control push button to drive the actuator in the CCW direction.

10 - Motor Stall – A flashing red LED indicates a stall condition exists and that the actuator has been prevented from reaching the position commanded by the control signal. A STALL of more than several seconds will cause power to be automatically removed from the motor circuit, placing the actuator in a safe mode. A reverse signal or a manual mode [CW] or [CCW] movement is required to clear the stall condition. A STALL condition can be initiated by a blockage in the valve or damper, cam limit settings that are inside of




Figure 3.

the electronically saved travel stop positions, or some other increase in the torque load on the actuator.

11 - Battery Charging* – A continuous yellow LED indicates that the battery charging circuit is active to either charge or maintain the voltage on the Battery.

12 - Battery Charged* – A continuous green LED indicates that the battery is fully charged. A flashing green LED indicates the actuator is running on battery power. This LED will turn off in Energy Save mode.

* **NOTE:** Battery Charging and Battery Charged LEDs may be lit at the same time depending on the battery charge state.

13 - Switch Trip – A continuous red LED indicates that one of the end-of-travel limit switches has been “tripped” by the respective cam; this LED is intended to aid initial actuator set-up.

4.2 OPERATION MODE SELECTOR POT

The Universal Control Board is equipped with an Operation Mode Selector Pot which allows the user to select the 6 modes of operation during calibration and set-up. LED indicators around the knob correspond to each of the modes; RUN, Manual (MAN), SPAN, MID, ZERO and Calibrate (CAL). When the Universal Control Board mode dial is set to any mode, the corresponding LED turns on, indicating the mode is selected.

In MAN (Manual) and CAL mode the unit will ignore any external control signals and respond only to the on-board push buttons (it should be noted that if the unit is equipped with an optional back-up battery and loss of power should occur while in MAN and CAL mode, the unit will drive to the selected “Power Fail” position).




Figure 4.

4.3 CONTROL MODE SELECTOR POT

The Universal Control Board is equipped with a Control Mode Selector Pot which enables the user to select between various “On/Off Control” and “Position Control” modes.




Figure 5.

4.4 TRAVEL LIMIT CAM AND SWITCH OPERATION

With the Universal Control Board installed, the travel limit stops are set electronically as the Zero and Span position. Two limit switches operated by the cams on the output shaft are safety stops. Their intended function is to prevent damage in the event of a failure of the electronic limits. Therefore: Each cam must be set to operate the switch slightly outside of the electronic Zero and Span position range. Failure to set the cams properly may cause the actuator to stall when it cannot reach the commanded and electronically set end of travel position. The bottom limit switch determines clockwise safety stop position. The next limit switch, up from the bottom, determines the counterclockwise safety stop position. Auxiliary switches and the corresponding cams will be the third and fourth up from the bottom.

Travel limits, also referred to as “end of travel stops”, are the precise positions to which the actuator will drive. For “2 Wire” or “3 Wire” On/Off operation, travel limits are set at the full clockwise (CW) and full counterclockwise (CCW) ends of travel.

To simplify the process of setting the precise travel limit positions, the ADC-Series provides two On/Off travel limit types. CW, CCW and MID may be set electronically via the “Smart” limit utility or CW and CCW may be set mechanically by selecting the “Cam” limit type.

SMART LIMIT

When “Smart” is selected as the limit type, the microprocessor stores the exact positions where the actuator will stop at each end of travel or mid position. Setting the “Smart” limit positions for the ZERO (typically CW), MID, and SPAN (typically CCW) positions is done with the selector knob and [ENTER] button in the Operation field of the Universal Control board. To use the Smart limit features, the Feedback Potentiometer must be installed, connected and calibrated and the travel stop cams must be set to trip the switches slightly beyond the desired “electronic” stop positions for ZERO and SPAN. The end-of-travel limits on ADC actuators can be entered and saved between 0° and 270° of travel. For 180° and 270° rotation alternate potentiometer gearing is required (refer to option code). For “Three-Position” operation, limits must be entered and saved using the “Smart” Limit!

CAM LIMIT

When “Cam” is selected as the limit type, two limit switches operated by the stainless steel cams on the output shaft extension are used to determine the exact positions where the actuator will

stop at each end of CW and CCW travel. The bottom limit switch determines the clockwise stop position. The next limit switch, up from the bottom determines the counterclockwise stop position. The “end of travel limit” switches can be adjusted to provide from 5 to 320 degrees of actuator rotation. For “Three-Position” operation, limits must be entered and saved using the “Smart” Limit!

4.5 BUILT-IN HEATER/ THERMOSTAT FEATURE

The Universal Control Board is equipped with a built-in Heater/Thermostat Option that can be enabled for low-temperature use (environments where the temperature will drop below 32° Fahrenheit), high-humidity use (“tropical” environments), or disabled completely to conserve power, in environments where the climate is stable and/or controlled.

NOTE: All heater modes are disabled in “Energy Save” mode. The Heater/Thermostat is enabled/disabled by sliding a switch on the Universal Control Board. See graphic below for proper positioning:




Figure 6.

4.6 TORQUE LIMIT

The actuator is equipped with a torque limit feature; see **Figure 7** for identification of the torque setting potentiometer (located under the overlay, between the CW and CCW pushbuttons).




Figure 7.

There are two standard settings as follows:

“Small” actuator; 150, 300, or 600 lb-in torque rating.

“Large” actuator; 1000, 1500, 2000, 2500, or 3000 lb-in torque rating.

NOTE: The sections marked “Special” will be utilized only by the factory to limit the torque output to a value below the actuator’s maximum rated torque.




Figure 8.

WARNING

FAILURE TO SET THE TORQUE VALUE IN THE APPROPRIATE REGION FOR THE ACTUATOR SIZE WILL VOID THE PRODUCT WARRANTY.

5. MAIN ACTUATOR POWER

The identification label on each actuator specifies the model number, serial number, actuator power voltage and current requirements for the actuator. It is important to verify the correct actuator voltage and control voltage prior to wiring the actuator.




Figure 9.

5.1 115VAC OR 230VAC POWER WIRING

If using 115VAC or 230VAC as the MAIN Input Power:

115/230 VAC must be supplied constantly to the Universal Control Board as follows:

- Terminal A (AC L1/HOT)
- Terminal B (AC L2/NEUT)

5.2 24VAC POWER WIRING

If using 24VAC as the MAIN Input Power: 24VAC must be supplied constantly to the Universal Control Board as follows:

- Terminal 17 (24AC HOT)
- Terminal 18 (24AC NEUT)

WARNING

IF USING 24VAC TO POWER THE ACTUATOR, A DEDICATED POWER SUPPLY OR ISOLATION TRANSFORMER MUST BE USED.

5.3 12VDC OR 24VDC POWER WIRING

If using 12VDC or 24VDC as the MAIN Input Power: 12/24 VDC must be supplied constantly to the Universal Control Board as follows:

- Terminal 19 (DC POS)
- Terminal 20 (DC NEG)

6. ON/OFF CONTROL (See Figure 5)

6.1 THE THREE METHODS OF ON/OFF CONTROL:

The On/Off Control mode allows the actuator to drive in a desired direction in response to an application of voltage to the desired inputs. The different modes are as follows:

“2 WIRE CW”

The actuator will default to the CCW position when main actuator power is present; the actuator will drive CW when the “CW” control power is energized.

“2 WIRE CCW”

The actuator will default to the CW position when main actuator power is present; the actuator will drive CCW when the “CCW” control power is energized.

“3 WIRE JOGGING” OPERATION (OPEN/STOP CLOSE)

The actuator will drive CCW when the “CCW” control power is energized and drive CW when the “CW” control power is energized; if control power is removed mid-travel, the actuator will stop in position. The actuator will drive to the programmed “MID” position when the “MID” control power is energized. The “MID” position is optional and can be set anywhere inside of the CW and CCW end-of-travel positions settings to provide a Three-Position “Center-Off” position, or a “Dribble Feed” position.

“3 WIRE LATCHING” OPERATION

The actuator will “latch” and drive CCW when the “CCW” control power is momentarily energized. The actuator will “latch” and drive CW when the “CW” control power is momentarily energized. After energizing the control power can be removed, as the direction of travel is “latched” in and the unit will continue to drive to the respective travel limit. The actuator will “latch” and drive to the programmed “MID” position when the “MID” control power is momentarily energized. The “MID” position is optional and can be set anywhere inside of the CW and CCW end-of-travel positions settings to provide a Three-Position “Center-Off” position, or a “Dribble Feed” position.

6.2 ON/OFF CONTROL SIGNAL WIRING




Figure 10.

HIGH VOLTAGE:

To control the actuator with a high voltage signal (115VAC or 230VAC): Connect AC L2/NEUT to terminal F on the Universal Control Board. Energize AC L1/HOT at terminal C on the Universal Control Board to drive the actuator clockwise (CW). Energize AC L1/HOT at terminal D on the Universal Control Board to drive the actuator to the “MID” position. Energize AC L1/HOT at terminal E on the Universal Control Board to drive the actuator counterclockwise (CCW).

LOW VOLTAGE:

To control the actuator with a low voltage signal (12VDC, 24VDC or 24VAC): Connect 12/24DC NEG or 24AC NEUT to terminal 8 on the Universal Control Board. Energize DC POS or 24AC HOT at terminal 9 on the Universal Control Board to drive the actuator clockwise (CW). Energize DC POS or 24AC HOT at terminal 10 on the Universal Control Board to drive the actuator to the “MID” position. Energize DC POS or 24AC HOT at terminal 11 on the Universal Control Board to drive the actuator counterclockwise (CCW).

On / Off (2 Wire and 3 Wire) Control Wiring




Figure 11.

6.3 SET UP AND CALIBRATION

INITIAL SET UP

1. Remove actuator cover. Remove the override shaft from the actuator cover bushing; if the actuator is equipped with a handwheel, remove the handwheel before removing the top piece of the "two-piece" shaft from the cover bushing.
NOTE: Use caution to prevent damage to machined flange surface of cover casting; see cover replacement for additional information.
2. Select LIMIT type "Smart" or "Cam" by sliding the [Smart/Cam] switch down to select Cam or up to select Smart. Selecting Smart will enable other features on the board such as Position Feedback and "Three- Position" operation. Selecting Cam will allow the actuator to drive between the end-of-travel limit switch settings.
3. Select Control Method "2 Wire CCW", "2 Wire CW", or "3 Wire" by turning the selection potentiometer with a small flat blade screwdriver.

POTENTIOMETER CALIBRATION

Field installation of the Universal Control Board or replacement of the position tracking potentiometer requires calibration of the position tracking potentiometer prior to setting positions and values for ZERO, MID and SPAN. Universal Control Boards installed at the factory are fully calibrated at the factory and should not require further calibration.

To confirm proper potentiometer calibration:

1. Turn the Mode Selector Dial to [CAL] and press [ENTER] for 2 seconds.
2. Using the CW pushbutton, drive the actuator to the full clockwise position. - If the [CAL] LED is flashing, potentiometer calibration is required; proceed to step 3 below. - If the [CAL] LED remains on, calibration is not required; proceed to Setting ZERO, MID and SPAN Positions section below.
3. Loosen the set screw in the gear with a 1/16" hex wrench.
4. Rotate the gear until the LED remains on constantly; hold the gear in place and tighten the set screw. Ensure that the LED remains on after the set screw is tightened.
NOTE: The LED assists the user in locating the proper calibration window; it will flash faster as you approach the calibration window and slower as you move away from it.
5. Press the [ENTER] button to save the potentiometer setting.

SETTING ZERO, MID AND SPAN POSITIONS

Once (feedback potentiometer) calibration has been confirmed, set the desired "end of travel" positions. Make certain that the limit switch cams are set to operate the switches beyond the desired range for the ZERO and SPAN positions. ZERO and SPAN may be set at any position between 0° and 94° of travel (0° and 184° with "UL4" or "UL5" option; or 0° and 274° with "UL6" or "UL7" option).

Set ZERO (typically CW):

1. Turn the Mode Selector Dial to [ZERO] and press [ENTER] for 2 seconds. The [ZERO] LED will begin to flash.
2. Drive the actuator to desired clockwise position using the CW or CCW push button. If the "STALL" LED begins to flash; check to see if the limit switch cam is preventing actuator from reaching desired ZERO end-of-travel (the "Switch Trip" LED will be illuminated). If necessary back the cam off so that it will trip the switch slightly beyond the desired end-of-travel and the "Switch Trip" LED will go out.
3. Press the [ENTER] button to save the ZERO setting.

Set MID (MID position will auto-calculate between Zero and Span; if an alternate position is desired, proceed as follows):

1. Turn the Mode Selector Dial to [MID] and press [ENTER] for 2 seconds. The [MID] LED will begin to flash.
2. Drive the actuator to the desired MID or "THIRD" position using the CW or CCW push button.
3. Press the [ENTER] button to save the MID setting.

Set SPAN (typically CCW):

1. Turn the Mode Selector Dial to [SPAN] and press [ENTER] for 2 seconds. The [SPAN] LED will begin to flash.
2. Drive the actuator to desired counterclockwise position using the CW or CCW push button. If the "STALL" LED begins to flash; check to see if the limit switch cam is preventing actuator from reaching desired SPAN end-of-travel (the "Switch Trip" LED will be illuminated). If necessary, back the cam off so that it will trip the switch slightly beyond the desired end-of-travel and the "Switch Trip" LED will go out.
3. Press the [ENTER] button to save the SPAN setting.

VERIFY END-OF-TRAVEL SETTINGS:

1. Turn the Mode Selector Dial to [RUN].
2. Apply various control signals to verify operation.
3. Verify that the "Switch Trip" LED is not illuminated at either the ZERO or SPAN positions (if it is, "back" the respective end-of-travel cam "off" of the respective limit switch).
4. Replace actuator cover.

PROPER ACTUATOR COVER REPLACEMENT

NOTE: For actuators including hazardous location certification. Prior to installing cover, inspect machined flange surfaces for any damage, scratches, or dents. Damage, scratches, or dents that will not fit completely in a circle having a diameter of 1/64" will void hazardous location certifications. If such imperfections are present the damaged enclosure parts(s) must be replaced. Consult the factory for replacement parts.

1. Remove the override shaft from the actuator cover bushing; if the actuator is equipped with a handwheel, remove the handwheel before removing the top piece of the "two-piece" shaft from the cover bushing.
2. Install the override shaft on the square motor shaft; if the actuator is equipped with a handwheel, install the bottom piece of the "two-piece" shaft on the motor shaft and then install the top piece of the shaft onto the bottom piece of the shaft.
3. Align cover so that the override shaft will pass through the override bushing and carefully push it down so that the cover flange contacts the base flange.
4. Once the cover is properly seated, tighten the screws to secure the cover; a cross pattern is recommended for uniform distribution of load.

5. If the position indicator is not seated to the output/cam shaft, turn until it drops into place in order to ensure accurate visual position indication.

7. POSITION CONTROL (See Figure 5)

7.1 THE THREE METHODS OF POSITION CONTROL

The Position Control mode allows the actuator to modulate (change position) in response to a change in an analog or resistance control signal. The different modes are as follows:

"4-20MA CURRENT ANALOG" CONTROL

The actuator will modulate between positions in direct response to the change in the input current signal. Set 4 mA as the Zero position and 20mA as Span for normal operation or set 4mA as Span and 20mA as Zero for reverse acting.

"0-10VDC VOLTAGE ANALOG" CONTROL

The actuator will modulate between positions in direct response to the change in the input voltage signal. Set 0VDC as the Zero position and 10VDC as Span for normal operation or set 0VDC as Span and 10VDC as Zero for reverse acting.

"RESISTIVE" CONTROL (UP TO 10K OHM)

The actuator will modulate between positions in direct response to the change in the input resistive signal.

7.2 POSITION CONTROL SIGNAL WIRING




Figure 12.

ANALOG CONTROL WIRING

To control the actuator with a 4-20mA or 0-10V analog signal:
Connect mA / VDC - (NEG) to terminal 16 and mA / VDC + (POS) to terminal 15 on the Universal Control Board. Slide the [Input] switch up to select 0-10V or down to select 4-20mA.

RESISTIVE CONTROL WIRING

To control the actuator with a resistance signal such as 0- 135 Ohms: Connect Resistance Signal - (NEG) to terminal 14, Resistance Signal Wiper to terminal 13, and Resistance + (POS) to terminal 12 on the Universal Control Board. The board will respond to resistance signals up to 10K Ohms (minimum SPAN signal is 100 Ohms; i.e. signal = 0-100 Ohms).

NOTE: There is a current limiter on the Resistive Input circuit, if the current exceeds 50mA for more than 80 milliseconds, the input will shut off. If this happens, it can be reset by cycling Main power.




Figure 13.

7.3 SET UP AND CALIBRATION

INITIAL SET UP

1. Remove actuator cover. Remove the override shaft from the actuator cover bushing; if the actuator is equipped with a handwheel, remove the handwheel before removing the top piece of the "two-piece" shaft from the cover bushing.
NOTE: Use caution to prevent damage to machined flange surface of cover casting; see cover replacement for additional information.

2. Select LIMIT type "Smart" by sliding the [Smart/Cam] switch up to select Smart. Selecting Smart will enable other features on the board such as Position Feedback.
3. Select Control Method "Analog" or "Resistive" by turning the selection potentiometer with a small flat blade screwdriver.

POTENTIOMETER CALIBRATION

Field installation of the Universal Control Board option or replacement of the position tracking potentiometer requires calibration of the position tracking potentiometer prior to setting positions and values for ZERO, MID and SPAN.

Universal Control Board options installed at the factory are fully calibrated at the factory and should not require further calibration. To confirm proper potentiometer calibration:

1. Turn the Mode Selector Dial to [CAL] and press [ENTER] for 2 seconds.
2. Using the CW pushbutton, drive the actuator to the full clockwise position. - If the [CAL] LED is flashing, potentiometer calibration is required; proceed to step 3 below. - If the [CAL] LED remains on, calibration is not required; proceed to Setting ZERO, MID and SPAN Positions section below.
3. Loosen the set screw in the gear with a 1/16" hex wrench.
4. Rotate the gear until the LED remains on constantly; hold the gear in place and tighten the set screw. Ensure that the LED remains on after the set screw is tightened.
NOTE: The LED assists the user in locating the proper calibration window; it will flash faster as you approach the calibration window and slower as you move away from it.
5. Press the [ENTER] button to save the potentiometer setting.

SETTING ZERO, MID, AND SPAN POSITIONS

Once (feedback potentiometer) calibration has been confirmed, set the desired "end of travel" positions. Make certain that the limit switch cams are set to operate the switches beyond the desired range for the ZERO and SPAN positions. ZERO and SPAN may be set at any position between 0° and 94° of travel (0° and 184° with "UL4" or "UL5" option; or 0° and 274° with "UL6" or "UL7" option).

Set ZERO (typically CW):

1. Turn the Mode Selector Dial to [ZERO] and press [ENTER] for 2 seconds. The [ZERO] LED will begin to flash.
2. Drive the actuator to desired clockwise position using the CW or CCW push button. If the "STALL" LED begins to flash; check to see if the limit switch cam is preventing actuator from reaching desired ZERO end-of-travel (the "Switch Trip" LED will be illuminated). If necessary back the cam off so that it will trip the switch slightly beyond the desired end-of-travel and the "Switch Trip" LED will go out.
3. Apply the desired Analog Signal that will correspond with the Zero position (ie 4mA).
4. Press the [ENTER] button to save the ZERO setting.

Set MID (MID position will auto-calculate between Zero and Span; if an alternate position is desired, proceed as follows):

1. Turn the Mode Selector Dial to [MID] and press [ENTER] for 2 seconds. The [MID] LED will begin to flash.
2. Drive the actuator to the desired MID or "THIRD" position using the CW or CCW push button.
3. Press the [ENTER] button to save the MID setting.

Set SPAN (typically CCW):

1. Turn the Mode Selector Dial to [SPAN] and press [ENTER] for 2 seconds. The [SPAN] LED will begin to flash.
2. Drive the actuator to desired counterclockwise position using the CW or CCW push button. If the "STALL" LED begins to flash; check to see if the limit switch cam is preventing actuator from reaching desired SPAN end-of-travel (the "Switch Trip" LED will be illuminated). If necessary, back the cam off so that it will trip the switch slightly beyond the desired end-of-travel and the "Switch Trip" LED will go out.
3. Apply the desired Analog Signal that will correspond with the Span position (ie 20mA).
4. Press the [ENTER] button to save the SPAN setting.

VERIFY END-OF-TRAVEL SETTINGS:

1. Turn the Mode Selector Dial to [RUN].
2. Apply various control signals to verify operation.
3. Verify that the "Switch Trip" LED is not illuminated at either the ZERO or SPAN positions (if it is, "back" the respective end-of-travel cam "off" of the respective limit switch).
4. Replace actuator cover.

PROPER ACTUATOR COVER REPLACEMENT

NOTE: For actuators including hazardous location certification. Prior to installing cover, inspect machined flange surfaces for any damage, scratches, or dents. Damage, scratches, or dents that will not fit completely in a circle having a diameter of 1/64" will void hazardous location certifications. If such imperfections are present the damaged enclosure part(s) must be replaced. Consult the factory for replacement parts.

1. Remove the override shaft from the actuator cover bushing; if the actuator is equipped with a handwheel, remove the handwheel before removing the top piece of the "two-piece" shaft from the cover bushing.
2. Install the override shaft on the square motor shaft; if the actuator is equipped with a handwheel, install the bottom piece of the "two-piece" shaft on the motor shaft and then install the top piece of the shaft onto the bottom piece of the shaft.
3. Align cover so that the override shaft will pass through the override bushing and carefully push it down so that the cover flange contacts the base flange.
4. Once the cover is properly seated, tighten the screws to secure the cover; a cross pattern is recommended for uniform distribution of load.
5. If the position indicator is not seated to the output/cam shaft, turn until it drops into place in order to ensure accurate visual position indication.

7.4 DEADBAND ADJUSTMENT

Dead Band is the window of control signal change which the actuator will ignore. The sensitivity of the actuator to respond to changes in the control signal is adjustable.

Minimum Dead Band (1%) allows the actuator to respond to small control signal changes. Maximum Dead Band (3%) allows the actuator to ignore small control signal changes (such as noise on the control signal).

7.5 SIGNAL FAIL OPTIONS

In the event that the control signal to the actuator is lost and external power is still applied, the Signal Fail position selector switch on the Universal Control Board provides options for the actuator to drive to the Zero (minimum signal) position, the Span (maximum signal) position, or to remain at its "Last" (current) position. **NOTE:** If you use a 0- 10VDC control signal, the actuator cannot differentiate between a 0VDC signal and an actual loss of signal; therefore, it will drive to the "Zero" position regardless of the switch setting.

8. POSITION FEEDBACK AND STATUS INDICATORS

8.1 POSITION FEEDBACK

The Position Feedback provides an analog indication of the actuator output position scaled between the configured Zero and Span positions.




Figure 14.

4-20mA

The 4-20mA Feedback can be powered either internally (by the actuator) or externally (by the loop).

If the Position Feedback will be powered internally, connect as follows: NEG to terminal 5; POS to terminal 7.

If the Position Feedback will be powered externally, it is extremely important to terminate the customer supplied +24VDC to the correct terminal on the Universal Control Board. The Position Feedback switches are also important. The **Power** Switch should be down in the "Ext" position and the **Signal** Switch should be down into the "4-20mA" position. (See **Figure 15** for wiring options).




Figure 15.

The 4-20mA Feedback circuit will power down if no impedance is measured on the output terminals in both Normal and Energy Save Mode operation. This is to stop any unnecessary power drain while the 4-20mA feedback circuit is not connected. Keep the metering circuit connected to ensure that the feedback will be available as needed. If the actuator position changes and there is a metering circuit connected, then the feedback circuit will resume operation and track the position.

0-10VDC

The 0-10V Feedback can only be used with internally (by the actuator) supplied power.

The Position Feedback switches are also important. The Power Switch should be up into the "Int" position and the Signal Switch should be up into the "0-10V" position.

8.2 STATUS INDICATORS

AUXILIARY SWITCHES

Two auxiliary limit switches will provide position indication for customer use. The switches are dry contacts that can be used to operate other devices. Switches are single pole, double throw; rated for 11A, 1/2HP, 250VAC, CSA certified. (See Figure 14 for wiring)

POWER STATUS RELAY

The Power Status Relay is "high" if external voltage (12-24VDC, 24VAC power inputs to the board and the output from the Switching Power Supply to the board) is greater than 12.5V. The relay is "low" if external voltage drops below 10.5V and will alternate between "high" and "low" if the motor is stalled. (See Figure 14 for wiring)

BATTERY STATUS RELAY

The Battery Status Relay is "high" if battery is present ($V_{bat} \geq 6V$) and fully charged (Charger current is $<10mA$); if the relay switches to "low" the back-up battery should be checked/replaced. **NOTE:** After a loss of external power, the Battery Status Relay may show "low" for a period of time while the battery is charging. (See Figure 14 for wiring).

NOTE: THE POWER STATUS RELAY AND BATTERY STATUS RELAY ARE SOLID STATE COMPONENTS RATED FOR 50MA AND 250VAC MAX; THEY ARE NOT TRANSIENT PROTECTED AND ARE INTENDED FOR LOW VOLTAGE, LOW CURRENT SIGNALS ONLY.

9. POWER MANAGEMENT

9.1 BATTERY

WARNING

THIS UNIT CONTAINS A SEALED LEAD ACID BATTERY, REGULAR CHARGING IS NECESSARY WITH STORAGE LONGER THAN THREE MONTHS. TO CHARGE THE BATTERY, APPLY ONE OF THE INPUT VOLTAGES TO THE CORRESPONDING INPUT ON THE ACTUATOR, (NOT DIRECTLY TO THE BATTERY) AND LEAVE POWERED FOR AT LEAST TWENTY-FOUR HOURS. HIGH AMBIENT TEMPERATURES CAN SHORTEN STORAGE LIFE. IT IS RECOMMENDED THAT THE BATTERY BE STORED AT $22^{\circ}C \pm 5^{\circ}C$ ($72^{\circ}F \pm 9^{\circ}F$). INSPECT THE BATTERY UPON RECEIPT, BEFORE INSTALLATION, AND AT REGULAR MAINTENANCE INTERVALS. REMOVE THE BATTERY FROM THE DEVICE FOR LONG-TERM STORAGE. FAILURE TO FOLLOW THIS CHARGING REQUIREMENT MAY RESULT IN REDUCED EFFECTIVE BATTERY LIFE.

WARNING

BATTERY PACK REPLACEMENT SHOULD NEVER BE PERFORMED WHEN AN EXPLOSIVE ATMOSPHERE IS PRESENT. DISCONNECT POWER FROM ACTUATOR BEFORE REMOVING COVER AND REPLACING BATTERY PACK. FAILURE TO FOLLOW THESE REQUIREMENTS MAY RESULT IN DAMAGE OR PERSONAL INJURY! NON-SPILLABLE BATTERY MUST BE RECYCLED OR DISPOSED OF ACCORDING TO LOCAL ORDINANCE.

With the battery backup (included with options UL2, UL3, UL4, UL5, UL6 & UL7), the actuator will sense the loss of main input power to the Universal Control Board and immediately switch to internal battery power. When line power returns, the actuator will automatically resume normal operation.

The battery charging voltage has been designed for optimum battery performance. When the charging circuit is active (even when topping off charge or in sleep mode), the yellow Charging LED will light. After reaching full charge, the green Charged LED will light. *Fully charged, the battery voltage will reach approximately 13.6 volts. This voltage is designed to vary with temperature, and could be as high as 14.4 volts if in a very cold environment, or as low as 12.8 volts if in a very warm environment. This is normal operation. A battery case that is swollen or cracked must be replaced. Please consult the factory for replacement. If the battery does not reach full charge (the green Charged LED remaining on and the yellow Charging LED turning off) within 48hrs, consult the factory or your local representative.

* **NOTE:** Battery Charging and Battery Charged LEDs may be lit at the same time depending on the battery charge state.

Replacement battery packs should be stored only after a full charge and at less than $80^{\circ}F$. Temperature can affect battery shelf life. Generally lower temperatures will increase shelf life while higher temperatures will decrease shelf life. When recharging battery packs, they should only be recharged from the Universal Control Board charging circuit, which is calibrated to provide the proper voltage and current for maximum battery pack life, or from a Neles recommended battery charger.

The only suggested maintenance is to examine, and if necessary, replace the battery every two years. Battery life can vary with temperature. Cooler environments will generally prolong battery life and under ideal conditions ADC batteries will last in excess of five years. To change the battery, perform the following:

1. Disconnect power to the actuator.
2. Remove actuator cover and set aside carefully so as not to damage the machined flange.
3. Disconnect battery connection at the Universal Control board.
4. Unhook one side of the battery hold-down strap.
5. Remove the battery.
6. Install new battery and replace hold-down strap.
7. Plug battery connector into the connector into the Universal Control Board.
8. Replace actuator cover.
9. Apply power.

9.2 POWER FAIL CONTROLS

The ADC-Series Universal Control Board is designed to be easily configured to drive to either the CW, CCW or MID position upon loss of actuator power. This is the power loss or "Fail" position.

When designating MID as the power loss or "Fail" position, the limit type must be set at "Smart" and the MID position must have been entered and saved in the "Operation" field otherwise the Actuator will calculate a default MID position between the calibrated Zero and Span positions.

The ADC-Series Universal Control Board is designed to provide continuing service in the event of a loss of external power. Upon power loss the ADC-Series actuator, equipped with a Back-Up Battery, can be configured to drive the actuator and "Park" immediately at the designated power loss Fail position and "go to sleep".

In "Multi" mode it will continue to cycle on battery power while a control signal and adequate battery power remain available. When "Multi" is selected, the actuator will cycle until a low battery power condition is detected then automatically drive to and remain at the designated power loss or Fail Position.

In "Multi" mode a fully charged battery will provide up to ten complete 90 degree cycles under optimum conditions. Upon reaching the power loss position, the system will "go to sleep" until input power is restored.

9.3 "WAKE UP" AND MANUALLY DRIVE ACTUATOR

Manually Drive the Actuator (Using the Battery) During Power Outage (If using "Park" Power Fail Control selection) After the battery drives the actuator to the Power Loss Position, the Universal Control Board powers down and remains in "sleep" mode until external power returns. To "wake" the actuator, to control it with the external control signal or to enable the CW or CCW push buttons for manual control, move the Power Fail Controls switch to "Multi" mode and press [Enter]. This will "wake" the electronics and the actuator can be manually operated via the CW or CCW push buttons until low battery power level is detected. To "park" the actuator and revert it back to sleep mode flip the Power Fail switch back to "Park" mode and the actuator will drive to the fail position and go back to sleep.

9.4 ENERGY SAVE MODE

The ADC-Series Universal Control Board is equipped with an "Energy Save" mode in which the unit will "doze" when a control signal change is not detected after a one-minute time-out; this is especially beneficial in solar applications where the continuous power draw can be minimized considerably by using "Energy Save" mode. Once a signal change is detected, the unit will "wake" and

respond; if no additional changes are made within one minute, the unit will again enter the "doze" cycle.

Selecting "Energy Save" Mode To select "Energy Save" mode, simply slide the Power Consumption switch down; to return to "Normal", simply slide the switch up.

NOTE: All heater modes are disabled in "Energy Save" mode.

10. BOARD INSTALLATION / REPLACEMENT

10.1 SAFETY PRECAUTIONS

WARNING

DANGEROUS VOLTAGES ARE PRESENT INSIDE THE ACTUATOR COVER UNLESS THE POWER SUPPLY TO THE ACTUATOR HAS BEEN SHUT OFF OR DISCONNECTED. USE EXTREME CAUTION WHENEVER WORKING ON THE ACTUATOR WITH THE COVER REMOVED.

10.2 SAFETY PRECAUTIONS APPLICABLE TO UNITS EQUIPPED WITH A BACK-UP BATTERY

WARNING

WHEN OPTIONAL BATTERY IS CONNECTED TO BOARD, THE UNIT MAY DRIVE!

BEWARE OF MOVEMENT OF THE FINAL DRIVE ELEMENT AND ANY LINKAGE BETWEEN IT AND THE ACTUATOR!

KEEP HANDS, OTHER PARTS OF THE BODY, TOOLS AND OTHER OBJECTS OUT OF THE WAY OF MOVING PARTS. FAILURE TO DO THIS MAY RESULT IN DAMAGE OR PERSONAL INJURY!

10.3 PARTS VERIFICATION

LOCATE THE REPLACEMENT BOARD KIT VCK00003 FOR ADC, OR VCK00019 FOR LADC

INSPECT ALL PARTS AND HARDWARE TO BE CERTAIN THAT IT IS FREE OF DAMAGE THAT MAY HAVE OCCURRED IN SHIPPING.

COLLECT THE TOOLS REQUIRED.

- 5mm Hex wrench
- 6mm Hex wrench
- 1/16 inch Hex wrench
- #1 Phillips screwdriver
- #2 Phillips screwdriver
- Small Flat Blade Screwdriver
- 9/64 inch Hex wrench
- Wire Cutters (to cut tie wraps)

11. BOARD REMOVAL

11.1 STEP BY STEP INSTRUCTIONS FOR THE REMOVAL OF A UNIVERSAL ADC/LADC-SERIES ACTUATOR CONTROL BOARD:




Figure 16.

Remove the actuator cover, using a 6mm Hex wrench for LADC models or a 5mm Hex wrench for ADC models. This is what the inside should resemble (LADC Shown).




Figure 17.

Remove the overlay from the VCB00010 Circuit Board.




Figure 18.

Remove the three Philips head screws that hold the VCB00010 Board in place with the #1 Philips screwdriver, and save them for later use.




Figure 19.

Unplug all cables attached to the VCB00010 and remove the board. Connections are coded to prevent miswiring.

12. BOARD INSTALLATION

12.1 STEP BY STEP INSTRUCTIONS FOR THE INSTALLATION OF A UNIVERSAL ADC/LADC-SERIES ACTUATOR CONTROL BOARD:




Figure 20.

Prior to installation, ensure that all switch and potentiometer settings on the replacement board match that of the original board.

Connect the lower power supply cable to the VCB00010.

Connect the potentiometer, thermal cut-out, motor harness, and limit switches; as shown in **Figure 19**.




Figure 21.

Connect the upper power supply cable and the auxiliary limit switch cables as shown in **Figure 21**.




Figure 22.

Secure wires as shown in **Figures 19 and 22** to avoid contact with moving parts.

Re-install the three screws that secure the VCB00010 board to the bracket as shown in **Figure 18**.




Figure 23.

Re-install the board overlay.




Figure 24.

The actuator is now ready to be re-calibrated and set up for your application. Please refer to sections 4 through 9 of this manual for calibration and set up procedures and option settings.

13. REASSEMBLY




Figure 25.

NOTE: For actuators including hazardous location certification. Prior to installing cover, inspect machined flange surfaces for any damage, scratches, or dents. Damage, scratches, or dents that will not fit completely in a circle having a diameter of 1/64" will void hazardous location certifications. If such imperfections are present the damaged enclosure part(s) must be replaced. Consult the factory for replacement parts.

Once the actuator is calibrated and set for the application, verify operation. Locate the over-ride shaft (remove from cover bushing) and install it on the square shaft of the motor/gearbox. (**NOTE:** If the actuator is equipped with a handwheel, install the bottom part of the two-piece shaft on the motor/gearbox shaft, and then install the top part of the two-piece shaft onto the bottom shaft)




Figure 26.

Use the override shaft as a guide the align and re-install the cover onto the base and secure it with the screws that were previously removed.

14. TABLE 1: DEFAULT SETTINGS AND MODES

Board Section	Function	Condition	State
Position Feedback	Power	External	Switch Down
	Signal	4-20mA	Switch Down
On/Off Control	Control Mode	2 Wire CCW	Pot Full CCW
Position Control	Input	4-20mA	Switch Down
	Signal Fail	Zero	Switch Up
	Dead Band	Min	Pot Full CCW
Power Fail Controls	Park/Multi	Park	Switch Up
	CCW/Mid/CW	CW	Pot Full CW
Limit	Smart/Cam	Smart	Switch Up
Power Consumption	Normal/Energy Save	Normal	Switch Up
Operation	Mode Selector	Run	Pot Full CCW
Heater Control	Humid/Low-Temp/Off	Off	Switch Down

15. TROUBLESHOOTING

Symptom: Actuator Stall LED is blinking in a mid-travel position.

Fix: This could be due to hunting; increase actuator Deadband or adjust controller's setpoint tolerance.

Symptom: Actuator does not respond to 4-20mA or 0-10V control signal.

Fix: Verify that Analog Position Control Mode has been selected. If the problem persists calibration is required.

Symptom: No Feedback in Energy Save mode.

Fix: If the Feedback wires are removed from the terminal block, even briefly, the Feedback signal is turned off; ensure the wires are connected and cycle power to reinstate Feedback signal.

Symptom: LED's shut off after a minute.

Fix: Check to see if Energy Save mode has been selected; LEDs are turned off after one minute in Energy Save mode in order to reduce power consumption.

16. GENERAL OPERATING INFORMATION

For enclosure specifications and dimensions, see (Tables 1-2 and Figure 27).

16.1 ENCLOSURE RATINGS AND PRODUCT

Certifications Neles offers two versions of ADC-Series actuator enclosures: the "W" enclosure is weathertight, and the "WX" enclosure which is weathertight and explosion-proof.

16.2 OPERATING TEMPERATURE LIMITS

ADC-Series actuators are designed to operate in ambient environments between -40°F (-40°C) and 130°F (55°C). In outdoor applications where ambient temperatures exceed 80°F, actuators should be shielded from direct sunlight. In applications with high media temperatures, insulating blankets, heat shields and/or extended mounting shafts should be used to maintain ambient temperatures at the actuator within normal operating limits.

Activation of the heater and thermostat option is recommended for all outdoor applications and may also be used to dry condensation in high humidity environments.

16.3 ACTUATOR MOUNTING

The actuator may be mounted in any position including upside-down. It must be firmly secured to a direct mount flange or sturdy mounting bracket. A minimum of four bolts with lock washers should be used to secure the actuator to the bracket. Flexibility in the bracket is not allowed, and backlash, or "play", in the coupling should be minimized. The actuator output shaft must be in line (centered) with the valve shaft to avoid side-loading the shaft. See (Figure 27) for output drive dimensions and mounting hardware specifications.

WARNING

FAILURE TO USE MANUAL OVERRIDE PROPERLY COULD RESULT IN DAMAGE TO THE ACTUATOR GEARING. ENSURE THAT THE OVERRIDE IS FULLY DISENGAGED AND DO NOT USE EXCESSIVE FORCE WHEN MANUALLY POSITIONING ACTUATOR. DO NOT DRIVE THE ACTUATOR BEYOND THE TRAVEL LIMIT SETTINGS. FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN DAMAGE TO THE ACTUATOR AND/OR FINAL DRIVE ELEMENT.

16.4 MANUAL OVERRIDE

WARNING

MANUAL OVERRIDE OF THE ACTUATOR IS INTENDED FOR USE WHEN POWER IS NOT AVAILABLE. USING THE OVERRIDE SHAFT OR HANDWHEEL (IF APPLICABLE) WHEN POWER IS STILL PRESENT AT THE ACTUATOR COULD RESULT IN DAMAGE OR PERSONAL INJURY!

To use the manual override, push the override shaft down approximately 1/4 inch to disengage the motor from the gear train.

Failure to disengage motor prior to turning override will cause damage to the actuator. While holding the shaft down, turn the shaft with a wrench or handle to the desired position.

NOTE: The override shaft on actuators below 1000 lb•in must be rotated in the opposite direction of the desired direction of the output shaft. In actuators 1000 lb•in and above, the override and the output shaft turn in the same direction.

Do not drive the actuator beyond the limit switch settings; it is possible to damage installed options such as a feedback potentiometer. The manual override shaft must be returned to its fully upward position before the motor is re-engaged. Rotate the shaft slightly to align the spur gears until the shaft "springs" back to its re-engaged position.

NOTE: The rotation direction of the output may not be the same as the rotation of the override shaft!

16.5 LUBRICATION

All rotating power train components are permanently lubricated with multi-purpose Lithium grease suitable for the operating temperature range of the actuator. Additional lubrication is not required in normal operation.

16.6 PROBLEM PREVENTION

Most actuator problems result from improper installation.

- Incorrect Wiring and Set Up Make certain the actuator is wired correctly and travel stops are properly set before power is applied.
- Coupling, Alignment, and Mounting Do not add extra torque! Make certain that the mounting arrangement is sturdy, centered, properly aligned, and that all mounting hardware is secure and properly tightened.
- Moisture Replace the cover tightly and make certain conduit entry holes are sealed properly to prevent moisture infiltration.

16.7 WARRANTY

All V-Series actuators are backed by a 2 year warranty that covers materials and workmanship. The warranty shall expire 24 months from installation or 30 months from delivery; whichever comes first.

To request a Return Authorization for an actuator within the warranty period, please consult your local Neles distributor.

16.8 REPAIR SERVICE/SPARE PARTS

We recommend that electric actuators be directed to our Northeast Service Center for maintenance. The Service Center is equipped to provide rapid turn-around at reasonable cost and offer new product warranty with all reconditioned electric actuators.

For electric actuators outside of the warranty period, request a Return Authorization by calling the Northeast Service Center at (508) 595-5195; or by sending an e-mail to valvconservice@neles.com.

NOTE: When sending electric actuators to the Service Center for repair, do not disassemble them! The actuator should be relatively clean upon return. For further information on spare parts and service or assistance, visit our Web site at www.neles.com/products/actuators/electric-actuators

NOTE: When ordering spare parts, always include the following information:

- Actuator model number from the product nameplate
- Serial number from the product nameplate
- Part number and/or description

17. SPECIFICATIONS & TECHNICAL INFORMATION

Table 2																	
Torque Output (lb-in; lb-ft; Nm)	Duty Cycle (at/ below 104°F/ 40°C)	Duty Cycle (at max temp; 130°F/ 55°C)	12VDC			24VDC			24VAC			115VAC			230VAC		
			Cycle Time	Time ON / OFF at max. temp.	Current Draw	Cycle Time	Time ON / OFF at max. temp.	Current Draw	Cycle Time	Time ON / OFF at max. temp.	Current Draw	Cycle Time	Time ON / OFF at max. temp.	Current Draw	Cycle Time	Time ON / OFF at max. temp.	Current Draw
			(sec/90°)	(sec)	(Amps)	(sec/90°)	(sec)	(Amps)	(sec/90°)	(sec)	(Amps)	(sec/90°)	(sec)	(Amps)	(sec/90°)	(sec)	(Amps)
150; 12; 17	100%	75%	11	11 / 4	2.2	13	13 / 5	1.2	8	8 / 3	1.8	9	9 / 3	0.4	9	9 / 3	0.4
300; 25; 34	100%	75%	17	17 / 6	2.5	13	13 / 5	1.4	12	12 / 4	2.1	13	13 / 5	0.5	13	13 / 5	0.4
600; 50; 68	100%	75%	17	17 / 6	2.8	13	13 / 5	1.7	13	13 / 5	2.5	14	14 / 5	0.6	14	14 / 5	0.5
1000; 83; 113	100%	75%	21	21 / 7	4	14	14 / 5	2.4	15	15 / 5	3.5	15	15 / 5	0.9	15	15 / 5	0.6
1500; 125; 169	100%	75%	40	40 / 14	4	24	24 / 8	2.4	27	27 / 9	3.5	29	29 / 10	0.9	29	29 / 10	0.6
2000; 167; 226	100%	75%	40	40 / 14	4.3	33	33 / 11	2.4	28	28 / 10	3.5	29	29 / 10	0.9	29	29 / 10	0.6
2500; 208; 282	100%	75%	55	55 / 19	3.3	40	40 / 14	2	38	38 / 13	3.1	39	39 / 13	0.8	39	39 / 13	0.6
3000; 250; 339	100%	75%	60	60 / 20	3.7	42	42 / 14	2.2	40	40 / 14	3.5	42	42 / 14	0.8	43	43 / 15	0.6

Table 3 Specifications	
Temperature Range	-40°F to 130°F (-40°C to 55°C)
Conduit Connections	(2) 3/4" NPT all sizes (3/4" to 1/2" reducing bushings included)
Output	150 to 600 in-lbs: ISO 5211 F05 and F07 bolt circles, 3/4" female square standard; see "Dimensions" section and "How to Order" table for additional output options. 1000 to 3000 in-lbs: ISO 5211 F07 and F10 bolt circles, 1" female square standard; see "Dimensions" section and "How to Order" table for additional output options.
Voltage	12 VDC: 10.8 to 13.2 VAC 24 VDC: 21.6 to 26.4 VDC 24 VAC: 21.6 to 26.4 VAC, 60 Hz or 50 Hz 115 VAC: 103.5 to 126.5 VAC, 60 Hz or 50 Hz 230 VAC: 207 to 253 VAC, 60 Hz or 50 Hz
Limit Switches	(2) Single pole, double throw switches rated for 11A 1/2HP 250VAC CSA certified.
Motor	Brushless DC motor with Class B or better insulation; sub-fractional horsepower. Rated for 120 starts per minute
Lubrication	Permanently lubricated gear train and bearings
Gear Train	Hardened steel, machine cut spur gears
Approximate Weight	17 lbs (8 kg) for sizes up to 600 in-lb (ADC models) 31 lbs (14 kg) for sizes 1000 in-lb and above (LADC models)
Enclosure	Die cast aluminum; with a baked-on, super durable polyester powder coat finish
Cover Screws	Captive cover screws for models starting with ADC are Class 12.9, M6 x 1.0 x 30 mm socket head cap screw; tighten to between 48 - 72 in-lb /for non-lubricated fasteners). Captive cover screws for models starting with LADC are Class 12.9, M8 x 1.25 x 36 mm socket head cap screw; tighten to between 10 - 12 ft*lb /for non-lubricated fasteners).

17.1 DIMENSIONS





Figure 27.

17.2 ADC-SERIES UNIVERSAL CONTROL BOARD

Table 4 Control Board Specifications	
Input Impedance (Analog Control)	Voltage Input: 35K ohms Current Input: 200 ohms
Analog Control Signal	May be either 4-20mA or 0-10VDC (selectable via on-board slide switch) Fully compatible with ISA-S50. 1 as a type 4, class L, power isolated device. Input minus (-) and transmit minus (-) are tied together and isolated from power and earth ground.
Resistive Control Signal	Board will accept a resistance control signal as low as 0-100 ohms and as high as 0-10K ohms.
Position Out Signal	May be either 4-20mA or 0-10VDC (selectable via on-board slide switch) Minimum resistive load for voltage output: 1K ohm Maximum resistive load for current output: 500 ohm
Stall Protection	If the actuator cannot achieve the position commanded by the control signal, this feature will remove all power to the motor after 5 seconds. The actuator will not restore power to the motor until the control signal commands the actuator to drive in the opposite direction.
Power Loss Position	In the event of a loss of main power, user can choose either the Zero position or the Span, or Mid position, via selector pot, as the power loss "Park" position.
Power Fail Park or Battery Cycle	In the event of a loss of main power, user can choose either to drive the actuator immediately to the "Park" Power Loss Position or continue to cycle (if control signal is available) until low battery level is detected before driving to the "Park" position.
Control Fail Position	In the event of a loss of control signal (with power still supplied), user can choose either the Zero, Span or the Last position via slide switch NOTE: If the the minimum control signal = 0, the fail position must be Last
Position Potentiometer	360° Rotation, 0 ohms to 1k ohms.
Local Supervisory Control	User can select manual (MAN) to override control signal and drive actuator by pushing the CW or CCW buttons. Actuator may be manually positioned to any location between the existing Zero and Span settings. For additional range, reset the ZERO and Span locations.
Split Range Control	Actuator will accept split range control signal (i.e. 4-12mA or 12-20mA; 0-5V or 5-10V) with no wiring changes.
Reverse Acting	With no wiring changes required, the actuator may be calibrated to drive clockwise upon an increasing control signal, and counterclockwise upon a decreasing signal.
Dead Band	The amount of change in control signal that the actuator will ignore before the output shaft begins to move. Adjustable from 1% to 3%.

18. ADC-SERIES ACTUATORS BY MODEL NUMBER

Table 5										
How To Order - ADC-Series Electric Actuators (see note 1)										
Actuator Series	Enclosure Type		Torque		Board Options (see note 2)		Other Options (if desired)		Operating Voltage	
	Order Code	Description	Order Code	Description	Order Code	Description	Order Code	Description	Order Code	Description
ADC	W	Weathertight	150	150 in lb	UL2*	On/Off / Positioner Board with SLA Battery Back-Up	I1 (see note 3)	14mm Female Square Output	-UP	Universal Power: 12/24DC, 24AC, or 115/230AC
		NEMA 4/4X	300	300 in lb	UL4*	On/Off / Positioner Board 180-Degree with SLA Battery Back-Up	I2 (see note 3)	17mm Female Square Output		
			600	600 in lb	UL6*	On/Off / Positioner Board 270-Degree with SLA Battery Back-Up	MB (see note 4)	Modbus Communication		
	WX	Weathertight & Explosionproof					Y1 (see note 3)	15mm Female Keyed Output		
		NEMA 4/4X/7&9					Y2 (see note 3)	20mm Female Keyed Output		
							Z	Handwheel		
LADC	W	Weathertight	1000	1000 in lb	UL3*	On/Off / Positioner Board with SLA Battery Back-Up	I2 (see note 3)	17mm Female Square Output	-UP	Universal Power: 12/24 DC, 24AC, or 115/230AC
		NEMA 4/4X	1500	1500 in lb	UL5*	On/Off / Positioner Board 180-Degree with SLA Battery Back-Up	I3 (see note 3)	19mm Female Square Output		
			2000	2000 in lb	UL7*	On/Off / Positioner Board 270-Degree with SLA Battery Back-Up	I4 (see note 3)	22mm Female Square Output		
	WX	Weathertight & Explosionproof	2500	2500 in lb			MB (see note 4)	Modbus Communication		
		NEMA 4/4X/7&9	3000	3000 in lb			Y2 (see note 3)	20mm Female Keyed Output		
							Y3 (see note 3)	25mm Female Keyed Output		
							Z	Handwheel		

- Notes:
1. All ADC-Series actuators accept any of the following input voltages (12VDC, 24VDC, 24VAC, 115VAC and 230VAC), are rated for continuous duty cycle, include a holding brake, two auxiliary limit switches, 4-20mA or 0-10VDC, position feedback, wrench-operated manual override, CSA "C US" certification, and a heater/thermostat that can be user-enabled on the option board.
 2. Must select only one board option; all board options can be configured for On/Off or Modulating operation.
 3. The standard drive output for 150 - 600 lb-in actuators is a 3/4" female square; the standard drive output for 1000 - 3000 lb-in actuators is a 1" female square.
 4. The Modbus Communication option allows for controlling, and polling the unit for diagnostic information using a Modbus communication signal (RS-485; Two-Wire).

- **Enclosure "W"** (weathertight) is certified by CSA to meet specifications for NEMA 4/4X; IP 66 for weathertight and dust-tight, environments. It is intended for non-hazardous locations in indoor or outdoor use.
- **Enclosure "WX"** (weathertight & explosionproof) is certified by CSA to meet specifications for NEMA 7&9, hazardous locations, (Class I, Division 1, Groups C, and D; Class II, Division 1, Groups E, F, and G; Class III) as well as to meet NEMA 4/4X and IP 66 specifications.

Sample Model Code: ADCWX150UL2Y1-UP

Actuator Series	ADC
Enclosure Type	WX
Torque	150
Board Option	UL2
Other Options (if applicable)	Y1
Operating Voltage	-UP

(For enclosure specifications and dimensions see **Table 2** and **Figure 27**).

- **Torque = Breakaway Torque** Valvcon™ Electric Actuators are rated at breakaway torque. This is the torque required to move a full load immediately upon power-up.




Figure 28.

19. ADDITIONAL ACTUATOR PRODUCTS AND ACCESSORIES FROM NELES

V-Series

- Up to 3000 inch pounds (250 lb-ft; 339 Nm) for On/Off, Modulating or Automatic Cycling applications
- 115VAC and 230VAC voltages
- 75% Duty Cycle (55% on 3000 lb-in models)
- NEMA 4/4X and NEMA 4/4X/7&9 enclosures
- CSA (C US) Certified
- CE Compliant
- Certified to ATEX Directive 2014/34/EU:
Ex d IIB T6 Gb, and IECEx CSA 14.0057X ("WX" models only)
- Standard Features: motor brake, tropical heater/thermostat, auxiliary limit switches, manual override and visual position indicator
- Available Options: Speed Control/Timer Board, metric and "keyed" female outputs and handwheel override

LCR Series

- Up to 600 inch pounds (50 lb-ft; 68 Nm)
- Economical actuators for Reversing applications
- 25% duty cycle (80% on 12VDC or 24VDC models)
- NEMA 4/4X enclosure
- 115VAC, 230VAC, 24VAC, 12 VDC and 24VDC voltages
- Options include extra limit switches and heater/thermostats
- Male output (standard) or female output (optional)

LCU Series

- Up to 600 inch pounds (50 lb-ft; 68 Nm)
- Economical actuators for Unidirectional applications
- 25% duty cycle (80% on 12VDC or 24VDC models)
- NEMA 4/4X enclosure
- 115VAC, 230VAC, 24VAC, 12 VDC and 24VDC voltages
- Options include extra limit switches and heater/thermostats
- Male output (standard) or female output (optional)

Q6-Series for Remote Solar Applications

- 600 inch pounds (50 lb-ft; 68 Nm)
- 12VDC
- Low current draw
- 80% Duty Cycle
- NEMA 4/4X/7&9
- CSA (C US) Certified

Valmet Flow Control Oy

Vanha Porvoontie 229, 01380 Vantaa, Finland.

flowcontrol@valmet.com

Tel. +358 10 417 5000.

www.valmet.com/flowcontrol

Subject to change without prior notice.

Neles, Neles Easyflow, Jamesbury, Stonel, Valvcon and Flowrox, and certain other trademarks, are either registered trademarks or trademarks of Valmet Oyj or its subsidiaries in the United States and/or in other countries.

For more information www.neles.com/trademarks

