


Replacement center section Jamesbury™ ball valves with ISO bonnet

Series 4000 model B

standard bore 1/2" – 2" (DN 15 – 50)

full bore 1/2" – 1½" (DN 15 – 40)

Installation, maintenance and
operating instructions



1. GENERAL

This replacement center section must be installed between the originally supplied Series 4000 Mod B end caps.

CAUTION:

LOOSE PARTS CONTAINED IN CENTER SECTION REPLACEMENT. BE CAREFUL WHEN REMOVING PACKAGING. KEEP BALL IN OPEN POSITION.

Removal and installation of the valve center section must be done in accordance with IMO-210. New body seals (inner and outer) shall be used when replacing the center sections. Body seal kits are shown in IMO-210 (Table 5) and are supplied with each center section replacement. The original body bolts must be used when reassembling the valve. If new body bolts are required, please contact the factory.

Subject to change without prior notice.

Neles, Neles Easyflow, Jamesbury, Stonel, Valvcon and Flowrox, and certain other trademarks, are either registered trademarks or trademarks of Valmet Oyj or its subsidiaries in the United States and/or in other countries.

For more information www.neles.com/trademarks

Valmet Flow Control Oy

Vanha Porvoontie 229, 01380 Vantaa, Finland.

flowcontrol@valmet.com

Tel. +358 10 417 5000.

www.valmet.com/flowcontrol

